200-Series, 300-Series User Manual



Important safety information

PLEASE READ CAREFULLY BEFORE INSTALLING PRODUCT IN VEHICLE

\triangle	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
≜ WARNING	WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
▲ CAUTION	CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.
CAUTION	CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.



Removing original equipment, adding accessories or modifying your vehicle could affect the vehicle's safety or make it illegal to operate in some jurisdictions.

Follow all product instructions and all instructions in your vehicle owner's manual regarding accessories or modifications.

Consult your country's and/or state's laws regarding operation of a vehicle with any accessories or modifications.

It is your sole responsibility to place, secure and use your Mio in a manner that will not cause accidents, personal injury or property damage. Always observe safe driving practices.

Do not mount your Mio in a way that may interfere with the safe operation of the vehicle, the deployment of air bags or other safety equipment.

Do not operate your Mio while driving.

Before you use your Mio for the first time, familiarize yourself with your device and its operation.

On main roads, the distance to an exit calculated by the Mio may be further than the distance shown on road signs. Road signs show the distance to the start of an exit while the Mio shows the distance to the next intersection, i.e., the end of the exit ramp or road. To prepare to exit a road, always follow distance information on road signs.

The use of information regarding safety or speed camera locations may be subject to local laws in the country of use. You are responsible for checking that you can legally use the information in your country or in the country where the information will be used.



Do not handle the Mio while it is hot. Let the product cool, out of direct sunlight.

At full power, prolonged listening to the Mio via headphones or earphones can damage the ear of the user,

CAUTION

Do not expose the Mio to direct sunlight in an unattended vehicle for prolonged periods. Overheating may damage the unit.

To discourage theft, do not leave your Mio, mounting bracket or any cables in plain view in an unattended vehicle.

Home Charger-specific safety information



To charge your Mio from the mains power, use the home charger (Model: PSAA05R-050; Input: 100-240V AC 50-60Hz; Output: 5V DC 1A Max) supplied by Mio as an accessory (may be sold separately). Using other home chargers with your Mio could result in serious injury or property damage.

Never use the charger if the plug or cord are damaged.

Do not expose the charger to moisture or water. Do not use the charger in a high moisture environment. Exposure to water may cause electrical sparks or fires.

Never touch the charger when your hands or feet are wet.

Allow adequate ventilation around the charger when using it to operate your Mio or charge the Mio internal battery. Do not cover the charger with paper or other objects that will reduce ventilation. Do not use the charger while it is inside a carrying case or other container.

Ensure that the charger is connected to a power source with the correct fitting and voltage requirements. The voltage requirements can be found on the home charger casing and/or packaging.

Do not attempt to service the charger as this could result in personal injury. Replace the charger if it is damaged or exposed to excess moisture.

Internal battery-specific safety information



The Mio contains a non-replaceable internal lithium-ion polymer battery. The battery may burst or explode if mishandled, releasing hazardous chemicals. To reduce the risk of fire or burns, do not disassemble, crush or puncture the battery.

Recycle or dispose of the battery safely and properly according to local laws and regulations. Do not dispose of the battery in fire or water.



Only use the correct mains power charger (sold separately) or in-vehicle charger supplied by Mio to charge the Mio internal battery.

Only use the Mio internal battery with the Mio unit.

The Mio battery will stop charging when the ambient temperature is less than 0°C (32°F) or more than 45°C (113°F).

Warning Notice to Drivers in California and Minnesota

State law prohibits drivers in California and Minnesota from mounting objects on their windshields while driving. Other Mio mounting options are recommended and an alternative mounting option is included in this box. Mio does not take any responsibility for any fines, penalties, or damages that may be incurred as a result of disregarding this notice. See California Vehicle Code Section 26708(a); Minnesota Statutes 2005, Section 169.71.

Failure to adhere to these warnings and cautions may lead to death, serious injury or property damage. Mio disclaims all liability for installation or use of the Mio that causes or contributes to death, injury or property damage or that violates any law.

Contents

Important safety information	2
Welcome	
Important information for using the manual	7
How do I get started?	8
How do I turn my Mio on for the first time?	8
How do I adjust the volume?	
How do I monitor the battery status?	
What are the main screens I will use?	
Main Menu screen	
Map screens	
How do I go from A to B?	
What if I miss a tum?	
How do I search for an address?	
Case Study: How do I search for an address?	
Using the Keyboard screen	19
Using the Destination Search screen	
Case Study: How do I navigate to multiple addresses?	
How do I skip a waypoint during a multi-stop trip?	25
How do I search for a Point of Interest (POI)? Case Study: How do I search for a Point of Interest?	26
•	
How do I save Favorites and My Home?	
How do I save a Favorite or My Home?How do I navigate to a Favorite?	
How do I navigate to a ravoitte:	
How do I edit the name of a Favorite?	31
How do I delete a Favorite?	
How do I navigate to a recent location?	
How do I view my route?	
3D Map screen	
2D Map screen Traffic Overview screen	
Route Overview screen	40
Turn-by-Turn screen	42
How do I use the Map Menu?	
How do I add an Avoid Area?	
How do I delete an Avoid Area?	
How do I delete all Avoid Areas?	
How do I preview a route?	46
How do I view my route statistics?	
How do I view statistics on my current route?	
How do I view statistics of my trips to date?	
How do I use NavPix?	
How do I manage my NavPix?	
Album management	50
NavPix management	52
How do I add or edit a NavPix description?	
How do I save a NavPix to a favorite?	55

How do I save a NavPix to a POI?	
Traffic	
How does my Mio receive traffic information?	
How will I know when a Traffic Event occurs?	
How do I view traffic details?	60
How do I know if a detour is recommended?	61
Traffic Messages	
What can I customize?	63
Route Options	64
Route Calculation 1/4	
Road Types 2/4	
Driver Alerts 3/4	
Data Recording 4/4	
Map Display 1/3	
Map Display 2/3	
Select Map 3/3	
Map POIs	
Volume	
POI Alerts	
GPS	
GPS Status	75
Setting your GPS mode	
Language	
Traffic Traffic System Status	
Traffic Event Notification	
Select event sorting type	
Power	
Keyboard	
How does predictive text (abc, def) work?	
Units 1/2	
Units 2/2	
Start-up	
Saved Info	
TutorialAbout	
Shop Demo	
What is MioMore Desktop?	
·	
Can I use MioMore Desktop with my computer?	90
How do I install MioMore Desktop onto my computer?	
MioMore Desktop features	
How do I keep MioMore Desktop up-to-date?	
MioMore Desktop Preferences	
MioMore Connect	
How do I search for a POI using MioMore Connect?	
How do I delete a POI from my Mio?	
My Maps	96
How do I install maps onto my Mio?	
How do I install maps from DVD?	
How do I remove maps from my Mio?	
My Map Preferences	
What is a Major Road Network map?	100
Photo Album	101
Toolbar	
How do I use Photo Album? How do I transfer pictures from Photo Album to my Mio?	
How can I view and edit pictures or albums on my computer?	

What else can I do with pictures and albums on my computer?	104
Photo Album Preferences	
Image Search	
How do I download NavPix from the internet?	106
How do I import NavPix to Photo Album?	
Mileage Reporter	107
How do I input my trip data?	
How do I export a mileage report?	108
How do I delete travel logs from my Mio?	
Mileage Reporter preferences	108
My subscriptions	109
Alerts	109
How do I install Safety Camera information?	109
How do I know which Safety Camera information is available?	109
Purchase a Subscription	109
Activate your Subscription	110
How do I update Safety Camera information on my Mio?	110
Custom POIs	
How do I install custom Points of Interest?	111
How do I delete a Custom POI File from my Mio?	112
Voice Transfer	113
How do I install a voice file?	113
How do I remove a voice file?	113
PIN Security	114
How do I register my Mio and set a PIN?	114
How do I remove the PIN from my Mio?	114
What if I forget the PIN for my Mio?	115
How do I backup my Mio?	116
Reference	117
Point of Interest categories	117
Traffic and other TMC Events	
For more information	122

Welcome

Thank you for purchasing this Mio. This manual has been prepared to guide you through the operation of your Mio from first set-up through to continuous use. Please read this manual carefully before using your Mio for the first time. Keep this manual in a safe place and use as your first point of reference.

Important information for using the manual

It is important to understand the terms and typographical conventions used in this manual.

Formatting

The following formatting in the text identifies special information:

Convention	Type of Information	
Bold	Mio components or items displayed on screen, including buttons, headings, field names and options.	
Italics	Indicates the name of a screen.	

Icons

The following icons are used throughout this manual:

Icon	Description
	Case study
\triangle	Warning

Terms

The following terms are used throughout this manual to describe user actions.

Term	Description
Тар	Press and release an item displayed on the touch screen.
Tap and hold	Tap and hold an item displayed on the touch screen for 2-3 seconds.
Select	Tap an item in a list or tap a command from a menu.

How do I get started?

The first time you use your Mio, it may take up several minutes to establish a GPS connection. For more information about GPS, refer to the GPS Frequently Asked Questions guide on the enclosed DVD.

How do I turn my Mio on for the first time?


To get started for the first time, complete the following steps:


- 1. Read the Important Safety Information on page 3.
- 2. **Position your Mio**

Follow the instructions below to position your Mio in your vehicle:


Note: Ensure that your Mio does not obstruct the driver's view, or interfere with the operation of the vehicle airbags and safety devices.

Mio Moov 200-Series





Mio Moov 300-Series



3. Turn your Mio on

Push the ${\bf Power}$ switch to the ${\bf ON}$ position.

Your Mio will turn on and display the Language screen.

4. Select your preferred language

From the Select Language screen, tap your preferred language.



- To prevent the Select Language screen from displaying on each start-up, clear the Show on start-up check box.
- You can change your preferred language while using your Mio (see "Language" on page 77).

5. Read the warning message

- The Safety Agreement screen will display after you have selected your preferred language.
 Read the Safety Agreement message.
- To confirm that you have read and understood the message, tap Accept. The Tutorial will display.

6. View the Tutorial

When you have accepted the Safety Agreement, the first Tutorial screen will display.

- To prevent the Tutorial from displaying again on start-up, clear the Show on start-up check box.
- To move forward through the Tutorial screens, tap

 To view the previous screen, tap

 ...
- To view the Tutorial again while using your Mio, see "Tutorial" on page 88.

Note: If you have maps installed from multiple continents, you may be prompted to select the maps you require. To use maps from a different continent at a later time, you can select a different map via the *Select Map* screen in the Select Map 3/3 preferences; refer to page 70.

When you have finished the *Tutorial*, the *3D Map* screen will display. If you have a GPS fix, your current location will be displayed on the map.

How do I adjust the volume?

The volume on your Mio can be adjusted by the volume control on the *Volume* preference screen.

To mute the volume from the map screens, tap and then tap ...

To adjust the volume, tap and hold to display the Volume preference screen.



For more information on how to adjust the volume on your Mio, see "Volume" on page 72.

How do I monitor the battery status?


Your Mio has an internal battery that when fully charged, should provide power for up to 3 hours.

The battery indicator light on the top of the Mio indicates the level of internal battery charge:

- Green battery full
- Orange battery charging

You can monitor battery power status on the *Power* screen.

To access the *Power* screen, tap NE and hold on the map screens.



How do I charge the battery?

The **Battery Status** bar displays **External Power** while the battery is charging; when the battery is fully charged, the **Battery Status** bar will display at 100%.

- To charge your Mio in a vehicle, plug the in-vehicle charger into on the bottom of your Mio and the other end into the vehicle power socket.
- To charge your Mio using your computer, plug the large end of the USB cable directly into a USB port on your computer (not a USB hub) and plug the small end into on the bottom of your Mio. To begin charging, ensure your Mio is turned off.
- To charge your Mio using a mains power socket, plug the mains power charger cable into on the bottom of
 the Mio and the mains power charger power pack into the power socket.

Note: The mains power charger is not included with all models and may be purchased separately.

What are the main screens I will use?

Main Menu screen

The Main Menu screen is your starting point for searching for a destination. The Main Menu screens also allow you to customize preferences, receive updated traffic information and make and receive phone calls.

The Main Menu can be accessed from the map screens by tapping or by tapping the status bar at the bottom of any screen.





Note: The Main Menu screens may differ from those displayed above, depending on your Mio model.

Map screens

There are five map screens used to view the route to your destination:

- 3D Map
- 2D Map
- Traffic Overview (if available)
- Route Overview
- Turn-by-Turn

The Map screens can be accessed from the Main Menu screen by tapping . The Map button displays the 3D Map screen, or the map screen you were last viewing.

You can cycle through the different map screens by pressing on any map screen (the name of the map screen will display briefly as your cycle through).



- For more information on the map screens, see "How do I view my route?" on page 34.
- For information on using the Map menu from the 3D Map and 2D Map screens, see "How do I use the Map Menu?" on page 44.

How do I navigate with GPS?

The Global Positioning System (GPS) is available at any time, free of charge, and is accurate to within 5m (15ft). GPS navigation is made possible by a network of satelites that orbit the Earth at around 20,200km (12,552mi). Each satelite transmits a range of signals which are utilized by GPS receivers, such as your Mio, to determine an exact location. Although a GPS receiver can detect signals from up to 12 satelites at any time, only four signals are required to provide a position or "GPS fix" (latitude and longitude), for vehicle navigation systems.

How does my Mio receive GPS signals?

Your Mio receives GPS signals via the internal GPS antenna. To guarantee the optimum GPS signal strength, ensure your Mio is outdoors, or in a vehicle outdoors, and has an unobstructed view of the sky. GPS reception is not usually affected by weather, however, very heavy rain or snow may have a negative effect on your reception.

How do I view my GPS status?

You can view your GPS status at any time from the map screens or the *Viewfinder* screen. Status at any time from the map screens or the *Viewfinder* screen. It is displays green when a GPS fix is established and red when a GPS fix is unavailable. To indicate the reception strength of a GPS fix, I displays between one and four green vertical bars.





- To view your GPS status in more detail, see "GPS Status" on page 75.
- To set your GPS mode, see "Setting your GPS mode" on page 76.
- For more information about GPS, refer to the GPS Navigation Frequently Asked Questions guide on the MioMore Desktop DVD.

How do I go from A to B?

Your Mio is equipped with maps that provide street-level detail for door-to-door navigation, including Points of Interest such as accommodation, parking areas, petrol stations, railway stations and airports.

When you	Then	
know the address of your destination	use the address-entry wizard to enter the address	
	see "How do I search for an address?" on page 17.	
want to make multiple stops	use the Multi-stop Trip Planner screen to enter multiple waypoints	
	see "How do I create a trip with multiple stops?" on page 21.	
need to find a named site, feature,	search for a Point of Interest	
landmark or public venue	see "How do I search for a Point of Interest (POI)?" on page 26.	
want to navigate to a NavPix ™ location	use the Go To NavPix screen to navigate to a preinstalled NavPix	
	see "How do I navigate to a NavPix?" on page 54.	
	Note: NavPix is only available on some models.	



WARNING For your safety, enter destination information before you start a journey. Do not enter a destination while driving.

What if I miss a turn?

Back-On-Track™ Automatic Rerouting

You will be redirected if you make a wrong turn. A message informing you that your route is being re-calculated will display at the top of the screen.

To cancel a route re-calculation tap . A warning will display, asking you to confirm the cancellation. If confirmed, both the re-calculation and your current route will be cancelled.

How do I search for an address?

Enter a destination using the *Destination Search*, *Keyboard* and *Preview* screens, which used together form an address-entry wizard.

This section provides a case study to help guide you through setting your destination.

Note: In some countries, you can search for your destination by postcode or zip code. If you are in the United Kingdom, and you know the postcode of your destination, you can search for it from the *Destination Search* screen by tapping **Postcode**, then entering a postcode of up to eight characters.

Quick Steps

- 1. Open the Destination Search screen
- 2. Select the country
- Search for the city/area
- 4. Search for the street
- Search for the house number
- 6. Tap



Case Study: How do I search for an address?

This case study will show you how to enter an address and how to navigate to it.

The address we will be using in this example is:

118 Mio Avenue New York New York 10017 USA.

Note: The above address is fictitious and used as an example only.

Tip: Before you enter your destination address, ensure that you have set your route preferences. For more information, see "Route Options" on page 64.

1. Open the Destination Search screen



The Destination Search screen will display.


Note: If this is the first time you are setting your destination and you have maps from more than one country installed, then the *Select a map* screen will display instead of the *Destination Search* screen. Go directly to step 2b. The next time you perform this procedure, the *Destination Search* screen will open as expected.

2. Select the country

Note: If you only have the maps of one country installed and selected, that country is selected for your destination by default and cannot be changed. Go to step 3.

a) From the Destination Search screen, tap

The Select a map screen will display.



Select USA from the list.
 The Destination Search screen will display.

3. Search for the City/Area

From the Destination Search screen, tap City/Area.
 The Keyboard screen will display.



b) Use the Keyboard screen to search for New York as the city or area of your destination, then tap the search result.

The Destination Search screen will display.



4. Search for the street name and house number

a) From the Destination Search screen, tap Street Address.
 The Keyboard screen will display.



Using the Keyboard screen

The *Keyboard* screen will display when you are required to enter text, such as when searching for a street name. Search results will be listed in matching order, with the closest matches appearing at the top of the list. A maximum of 99 results will display.

The Keyboard screen can display with various layouts depending on the information you need to enter, including alphabet, number, alternate characters and combinations of these.

You can also choose the type of keyboard you prefer from alphabetic, QWERTY and keypad. For more information, see "Keyboard" on page 83.









As you select each character, the first two results will display. Tap (2), then scroll to see more search results.

- To select a character or a search result, tap the character or search result.
- To delete a character, tap

 DEL
- To display more characters, tap 123, alt or abc, if available.

Using the **Destination Search** screen

The *Destination Search* screen is used to select your destination by area, street, postal or ZIP code, Points of Interest, intersection, city, area, state or country.



As you specify each part of the address, it will display at the top of the screen.

The available options will change to reflect the parts of the address still to be completed.

 Use the Keyboard screen to enter Mio Avenue as the street name of your destination, then tap the search result.

Note: There may be multiple matches for a particular street name. Long streets that run through several neighbouring areas, and common street names will produce search results ordered by their city or area name.

Enter the house number				
Go to Center of Street		^		
1 - 37, (0	dd)			~
1	2	3	4	5
6	7	8	9	0
<				V

 Use the Keyboard screen to enter 118 as the house number of your destination, then tap the search result.

The Preview screen will display.

Note: If house numbers are available, but not the one that you require, you may have to choose the same street in a neighbouring area. Press and select another search result.

If house numbers are not available for your selected section of the street the Preview screen will display.



d) Complete one of the following:

If you want to	Then	
navigate to your selected destinationn	tap Your route is calculated; the 3D Map screen will display.	
view the position on the map screen	tap the map to display the position on the 2D Map screen.	
view more information about your destination	tap More . The Destination Details screen will display.	
add the destination to a multi-stop trip	tap Add. The Multi-stop Trip Planner screen will display. The address is listed as a waypoint on the multi-stop trip. See "How do I create a trip with multiple stops?" on page 21.	
save the destination as My Home	tap Save. The New Favorite screen will display.	
	tap Save as My Home.	
save the destination as a favorite	tap Save . The <i>New Favorite</i> screen will display.	
	 tap Save as Favorite. 	

How do I create a trip with multiple stops?

You can use the *Multi-stop Trip Planner* screen to set multiple stops or waypoints for your trip. Your route will be calculated to go via each of these points in the specified order.

Waypoints can be added via the *Multi-stop Trip Planner* screen or by selecting **Location**, then **Add to Trip** from the pop-up *Map* menu on the *2D Map* or *3D Map* screen. You can save up to 198 multi-stop trips, each with up to 14 waypoints.

Note: Waypoints added, updated or deleted after a multi-stop trip has commenced will not affect the current route.

Quick Steps

- 1. Start your Multi-stop trip
- 2. Select the country
- 3. Search for the city/area
- 4. Search for the street and house number
- Add additional waypoints
- 6. Tap



Case Study: How do I navigate to multiple addresses?

This case study will show you how to set a multi-stop trip by entering multiple waypoints.

The address we will be using in this example is:

Note: The below address is fictitious and used as an example only.

671 Mio Avenue New York New York 10036 USA.

Tip: Before you enter your destination address, ensure that you have set your route preferences. For more information, see "Route Options" on page 64.

1. Open your Multi-stop Trip screen



The Multi-stop Trip Planner screen will display.

a) Tap Add.

The Add to Trip Menu will display.



b) Tap Address.

The Destination Search screen will open.

Note: You can also add waypoints using favorites, recent destinations, POI locations and NavPix.

2. Select the country

Note: If you only have the maps of one country installed and selected, that country is selected for your destination by default and cannot be changed. Go to step 3.

From the Destination Search screen, tap a) The Select a map screen will display.



b) Select USA from the list. The Destination Search screen will display.

3. Search for the City/Area

a) From the Destination Search screen, tap City/Area. The Keyboard screen will display.



b) Use the Keyboard screen to search for New York as the city or area of your destination, then tap the search result.

The Destination Search screen will display.



4. Search for the street name and house number

 a) From the Destination Search screen, tap Street Address. The Keyboard screen will display.



 Use the Keyboard screen to enter Mio Avenue as the street name of your destination, then tap the search result.

Note: There may be multiple matches for a particular street name. Long streets that run through several neighbouring areas, and common street names will produce search results ordered by their city or area name.



 Use the Keyboard screen to enter 671 as the house number of your destination. The Preview screen will display.

Note: If house numbers are available, but not that you require, you may have to choose the same street in a neighbouring area. If house numbers are not available for your selected section of the street the Destination Preview screen will display.



Tap Add.
 The waypoint is automatically saved and the Multi-stop-Trip screen will display.



e) Complete one or more of the following:

If you want to	Then	
add another waypoint	tap Add. The Add To Trip Menu will display.	
Note: Waypoints added after a multi-stop trip has commenced will not be included in the current route.	return to step 1a.	
navigate to your selected destination	tap tap The Preview screen will display.	
	tap The 3D Map screen will display the calculated route.	
change the order of your waypoints	 tap a destination point to move. The <i>Preview</i> screen will display. 	
	tap Up or Down . The <i>Multi-stop Trip Planner</i> screen will redisplay.	
delete all waypoints	tap Clear.	
delete one waypoint	tap a destination point to delete. The <i>Preview</i> screen will display.	
	tap Delete . The <i>Multi-stop Trip Planner</i> screen will redisplay.	
save the multi-stop trip as a favorite	tap Save. The New Favorite screen will display.	
	tap Save as Favorite. The Favorite will be saved.	

How do I skip a waypoint during a multi-stop trip?

To skip a waypoint during a multi-stop trip, complete the following:

1. Tap the map.
The *Map Menu* will display.



2. Tap Route, then Skip Waypoint.

The next waypoint will be skipped and the route recalculated to the following waypoint.

How do I search for a Point of Interest (POI)?

A POI is a named site, feature, landmark or public venue which can be displayed as an icon on the map. POIs are grouped by type, such as petrol stations, parks, beaches and museums.

Select a POI using the Destination Search, Keyboard and Preview screens, which used together form a POI-entry

Tip: You can also quickly search for certain POIs based upon your current location via the Main Menu screen.

This section provides a case study to help guide you through finding or setting your POI as a destination.

Quick Steps

- 1. Open the Destination Search screen
- 2. Select a country
- 3. Search for the City/Area
- Search for a POI 4
- Tap 5.



Case Study: How do I search for a Point of Interest?

This case study will show you how to enter an address and navigate to it.

The address used in this example is:

Note: The below address is fictitious and used as an example only.

Statue of Liberty **New York** New York 10004 USA

1. Open the Destination Search screen



The Destination Search screen will display.


Note: If this is the first time you are setting your destination and you have maps from more than one country installed, then the Select a map screen will display instead of the Destination Search screen. Go directly to step 2b. The next time you perform this procedure, the Destination Search screen will open as expected.

2. Select the country

Note: If you only have the maps of one country installed and selected, that country is selected for your destination by default and cannot be changed. Go to step 3.

a) From the Destination Search screen, tap

The Select a map screen will display.



Select USA from the list.
 The Destination Search screen will display.

3. Search for the city/area

From the Destination Search screen, tap City/Area.
 The Keyboard screen will display.



 Use the Keyboard screen to search for New York as the city or area of your destination, then tap the search result.
 The Select POI Category screen will display.



Tip: The list of categories is divided into Enabled Categories which are set to display an icon on the map screens, and Other POI Categories which will not display an icon.

4. Search for a POI

 a) Either tap Search by name to search in all POI categories, or select a category from the list. The Keyboard screen will display.



 Use the Keyboard screen to search for Statue of Liberty as your destination, then tap the search result. The Preview screen will display.



c) Complete one of the following:

If you want to	Then
navigate to your selected destination	tap Your route is calculated and displayed on the 3D Map screen.
view your position on the map screen	tap the map to display the position on the 2D Map screen
make a phone call to the POI	tap Call.
	Note: This feature is not available on all models.
view more information about your destination	tap More . The <i>Destination Details</i> screen will display.
add the destination to a multi-stop trip	tap Add . The <i>Multi-stop Trip Planner</i> screen will display. The address is listed as a waypoint on the multi-stop trip. See "How do I create a trip with multiple stops?" on page 21.
save the destination as My Home	tap Save. The New Favorite screen will display. tap Save as My Home.
save the destination as a Favorite	 tap Save. The New Favorite screen will display. tap Save as Favorite.

How do I save Favorites and My Home?

You can save up to 200 destinations as favorites, one of which can be saved as My Home.

You can save a favorite from the Preview screen after searching for an address, or from the Map Menu on the 3D or 2D Map screens. For more information, see "How do I use the Map Menu?" on page 44.

Can I save a NavPix to a Favorite?

You can save a NavPix to any of your existing favorites. For more information, see "How do I save a NavPix to a Favorite?" on page 55.

How do I save a Favorite or My Home?

- 1. Search for an address until the *Preview* screen is displayed.
- 2. Tap Save.

The New Favorite screen will display.



To change the name of the favorite, tap The Kevboard screen will display.



After you have entered a name for the favorite, tap The New Favorite screen will display.

Complete one of the following: 5.

If you want to	Then
save as a Favorite	tap Save as Favorite . The favorite is saved. The <i>Preview</i> screen will display.
save as My Home	tap Save as My Home . The favorite is saved as My Home. The <i>Preview</i> screen will display.

How do I navigate to a Favorite?







1. Tap the Favorite destination you want to travel to. The Preview screen will display.



2.

Your Mio will calculate the route from your current location. The 3D Map screen will display.

How do I navigate to My Home?

If you have not set an address as My Home, the first time you try to navigate to My Home you will be prompted to search for an address using the address-entry wizard.

Option 1 - Via the Main Menu







Your Mio will calculate the route from your current location. The 3D Map screen will display.

Option 2 - Via the Favorite Destinations screen







From the Favorite Destinations screen, select My Home. 1. The Preview screen will display.



2.

Your Mio will calculate the route from your current location. The 3D Map screen will display.

How do I edit the name of a Favorite?







From the Favorite Destinations screen, select a favorite to edit. 1. The Favorite Preview screen will display.



Tap Edit. 2. The Edit Name screen will display.



- To edit the name of the favorite, tap 3.
- 4. After you have edited the favorite name, tap The Edit Name screen will display.
- 5. Complete one of the following:

If you want to	Then
rename the Favorite	tap Save . The favorite is saved. The <i>Favorite Preview</i> screen will display.
save as My Home	tap Save as My Home . The favorite is saved as My Home. The <i>My Home Preview</i> screen will display.

How do I delete a Favorite?







1. From the Favorite Destinations screen, select a favorite to delete. The Preview screen will display.



2. Tap Delete.

The favorite is deleted. The Favorite Destinations screen will display.

How do I navigate to a recent location?

To make navigating to an address easier, your Mio will automatically save all your start locations and destinations in a list of recent locations.









Tap a recent location.
 The *Preview* screen will display.



2. Complete one of the following:

If you want to	Then	
calculate the route and open the 3D Map screen	Tap The 3D Map screen will display.	
view the full address details of the recent location	tap More . The <i>Recent Destination Details</i> screen will display.	
save the recent location as My Home	tap Save. The New Favorite screen will display. tap Save as My Home.	
save the recent location as a favorite	 tap Save. The New Favorite screen will display. tap Save as Favorite. 	

How do I view my route?

When a route has been calculated, the 3D Map screen will display. You will be directed to your destination by spoken and visual instructions.



The Map button cycles through the 3D Map, 2D Map, Traffic Overview, Route Overview and Turn-by-Turn™ screens.

3D Map screen

The 3D Map screen displays your current position and follows your direction of travel.

- Tap and drag the screen, to move across the map.
- Tap the map to view the Map Menu (see "How do I use the Map Menu?" on page 44).



Note: Depending on the country you are travelling in, the color of the direction and distance buttons may differ from the above example.

	Item	Description
1	Next instruction	The direction and name of the street to turn in to.
2	Direction and distance of next turn	The direction and distance to your next turn. Note: To repeat the spoken prompt of your next turn, tap the turn arrow.
3	Route	Your current route is highlighted.
4	Current position	Your current position is marked with ^.
5	Speed indicator	Displays when you exceed your set speed limit. For more information, see "Driver Alerts 3/4" on page 66.
6	Status bar	Displays one of the following: The name of the street you are located on Speed warnings Active POIs. Tap to display the <i>Main Menu</i> screen. Note: The Status Bar is replaced by current Traffic events, when Traffic is enabled. For more information, see "Traffic" on page 57.
7	Main Menu	The Main Menu button allows you to enter an address for your destination, customize preferences, receive updated traffic information and make and receive phone calls.

	Item	Description	
8	Distance and Time Information	Tap to expand and see the following options: Time km/h or mph (Speed) TTG (Time to Go) DTG (Distance to Go) ETA (Estimated Time of Arrival). Tap to cycle through the options. Note: During a Multi-stop trip, Time to Go, Distance to Go and ETA will display as: Time to Waypoint, Distance to Waypoint.	
9	Cancel route	Cancels your current route.	
10	Zoom	To view zoom options, tap . To zoom out, tap . To zoom in, tap .	
11	Мар	The Map button allows you to cycle through different map screens.	
12	Mute/unmute volume, TMC, Bluetooth™, phone, battery, GPS and compass information.	Tap NE to expand and see the following options: Mute/unmute volume TMC traffic status indicator. For more information, see "How does my Mio receive traffic information?" on page 57. Bluetooth and phone connection indicator. The icon is gray when Bluetooth is on, but a phone has not been paired. Battery charge indicator GPS status indicator The icon displays green when a GPS fix is established and red when a GPS fix is unavailable. To indicate the reception strength of a GPS fix between one and four green vertical bars are displayed.	
		NE Compass indicator	

2D Map screen

The 2D Map screen shows your current position (if a GPS fix is active) and surrounding street names. If a route has been calculated, the route and turns are highlighted. The 2D Map screen follows your direction of travel unless the Map Display preference is set to North (see "Map Display" page 69).

- Tap and drag the screen, to move across the map.
- Tap the map, to view the *Map Menu* (see "How do I use the Map Menu?" on page 57).



Note: Depending on the country you are travelling in, the color of the direction and distance buttons may differ from the above example.

	Item	Description
1	Next instruction	The direction and name of the street to turn in to.
2	Direction and distance of next turn	The direction and distance of your next turn. Note: To repeat the spoken prompt of your next turn, tap the turn arrow.
3	Route	Your current route is highlighted.
4	Current position	Your current position is marked with .
5	Status bar	Displays one of the following: The name of the street you are located on Speed warnings Active POIs. Tap to display the <i>Main Menu</i> screen. Note: The Status Bar is replaced by current Traffic events, when Traffic is enabled. For more information, see "Traffic" on page 57.
6	Main Menu	The Main Menu button allows you to enter an address for your destination, customize preferences, receive updated traffic information and make and receive phone calls.
7	Distance and Time Information	Tap to expand and see the following options: Time Km/h or mph (Speed) TTG (Time to Go) DTG (Distance to Go) ETA (Estimated Time of Arrival). Tap to cycle through the options. Note: During a Multi-stop trip, Time to Go, Distance to Go and ETA will display as: Time to Waypoint, Distance to Waypoint and ETA at Waypoint.
8	Cancel route	Cancels your current route.

	Item	Description	
9	Zoom	To view zoom options, tap . To zoom out, tap . To zoom in, tap .	
10	Мар	The Map button allows you to cycle through different map screens.	
11	Mute/unmute volume, TMC, Bluetooth™, phone, battery, GPS and compass information.	Tap NE to expand and see the following options: Mute/unmute volume TMC traffic status indicator. For more information, see "How does my Mio receive traffic information?" on page 57. Bluetooth and phone connection indicator. The icon is gray when Bluetooth is on, but a phone has not been paired. Battery charge indicator GPS status indicator The icon displays green when a GPS fix is established and red when a GPS fix is unavailable. To indicate the reception strength of a GPS fix between one and four green vertical bars are displayed. Compass indicator	

Traffic Overview screen

Depending on your Mio model traffic information may not be available or may require a traffic cradle.

The Traffic Overview screen displays a general overview of the traffic situation on your route, including all events in the immediate vicinity.

- Tap and drag the screen, to move across the map.
- Tap the map, to view the Map Menu (see "How do I use Map Menu?" on page 44)



	Item	Description	
1	Event icon	Displays icon to indicate type of event.	
2	Current position	Your current position is marked with .	
3		Your final destination.	
4		Tap to display the Event List screen.	
5	Status bar	Displays one of the following: The name of the street you are located on Speed warnings Active POIs. Tap to display the <i>Main Menu</i> screen. Note: The Status Bar is replaced by current Traffic events, when Traffic is enabled. For more information, see "Traffic" on page 57.	
6		Tap to display the <i>Traffic System Status</i> screen.	
7	Cancel route	Cancels your current route.	
8	Zoom	To view zoom options, tap . To zoom out, tap . To zoom in, tap .	
9	Мар	The Map button allows you to cycle through different map screens.	

	Item	Description	
10	Mute/unmute volume, TMC, Bluetooth™, phone, battery, GPS and compass information.	Mute/unmute volume TMC traffic status indicator. For more information, see "How does me Mio receive traffic information?" on page 57. Bluetooth and phone connection indicator. The icon is gray when Bluetooth is on, but a phone has not been paired. Battery charge indicator GPS status indicator The icon displays green when a GPS fix is established and red when a GPS fix is unavailable. To indicate the reception strength of a GPS fix between one and four green vertical bars are displayed. Compass indicator	en

Route Overview screen

The Route Overview screen gives you a bird's eye view of your trip.

Note: A route must first have been calculated for this screen to be available.

- Tap and drag the screen, to move across the map.
- Tap the map to view the Map Menu (see "How do I use the Map Menu?" on page 44).



Note: Depending on the country you are travelling in, the color of the direction and distance buttons may differ from the above example.

	Item	Description	
1	Next instruction	The direction and name of the street to turn in to.	
		Note: To repeat the spoken prompt of your next turn, tap the turn arrow.	
2	Direction and	The direction and distance of your next turn.	
	distance to next turn	Note: To repeat the spoken prompt of your next turn, tap the turn arrow.	
3	Route	Your current route is highlighted.	
4	Current position	Your current position is marked with ^; if visible.	
5		Your final destination.	
6	Scale bar	Displays map scale.	
7	Main Menu	The Main Menu button allows you to enter an address for your destination, customize preferences, receive updated traffic information and make and receive phone calls.	
8	Status bar	Displays one of the following:	
		The name of the street you are located on	
		Speed warnings	
		Active POIs.	
		Tap to display the Main Menu screen.	
		Note: The Status Bar is replaced by current Traffic events, when Traffic is enabled. For more information, see "Traffic" on page 57.	

Turn-by-Turn screen

The Turn-by-Turn screen displays the next four turns of your route, the turn direction, the street name and the distance to the turn. You can view all the turns in the list, using the up and down arrows. A route must first have been calculated for this screen to be available.

Note: A route must first have been calculated for this screen to be available.



Note: Depending on the country you are travelling in, the color of the direction and distance buttons may differ from the above example.

	Item	Description	
	Direction of turn	The direction of the turn. Your next turn is highlighted. Note: To Repeat the spoken prompt of your next turn, tap the turn arrow.	
2	Distance to turn	The distance to your next turn. Your next turn is highlighted.	
3	Instruction	The direction and name of the street to turn in to. Your next turn is highlighted.	
4	Next turn	Your next turn is at the top of the list.	
5	Upcoming turns	The direction and distance of upcoming turns.	
6	Main Menu	The Main Menu button allows you to enter an address for your destination, customize preferences, receive updated traffic information and make and receive phone calls.	
7	Status bar	Displays one of the following: The name of the street you are located on Speed warnings Active POIs. Tap to display the <i>Main Menu</i> screen. Note: The Status Bar is replaced by current Traffic events, when Traffic is enabled. For more information, see "Traffic" on page 57.	
8	Distance and Time Information	Tap to expand and see the following options: Time km/h or mph (Speed) TTG (Time to Go) DTG (Distance to Go) ETA (Estimated Time of Arrival). Tap to cycle through the options. Note: During a Multi-stop trip, Time to Go, Distance to Go and ETA will display as: Time to Waypoint, Distance to Waypoint and ETA at Waypoint.	

Iten	m	Description	
9 Scr	roll buttons	Allow you to	view each turn by moving up and down through the list.
10 Maj	ıp	The Map butt	on allows you to cycle through different map screens.
volu Blu pho GPS con	Ite/unmute Iume, TMC, uetooth™, one, battery, PS and mpass ormation.	The Map button allows you to cycle through different map screens. Tap to expand and see the following options: Mute/unmute volume TMC traffic status indicator. For more information, see "How does my Mio receive traffic information?" on page 57. Bluetooth and phone connection indicator. The icon is gray when Bluetooth is on, but a phone has not been paired. Battery charge indicator GPS status indicator The icon displays green when a GPS fix is established and red when a GPS fix is unavailable. To indicate the reception strength of a GPS fix between one and four green vertical bars are displayed. Compass indicator	

How do I use the Map Menu?

The Map Menu allows you to access navigational functions from the 3D Map and 2D Map screens.



Displaying the Map Menu

- Tap to display the 3D Map or 2D Map screen.
- 2. Tap and drag to move around the map to your selected location.
- 3. Tap the map. The Map Menu will display.

Map Menu options

The following options are available via the Map Menu:

Menu Option	Description	
Navigate To	Calculates a route from your current location, if your Mio has a GPS fix.	
Show Details	Displays the <i>Preview</i> screen from where you can: View details of the location Add the location to your multi-stop trip Save the location as a favorite Navigate to the location. Note: If the cross-hairs are positioned over a traffic event, Show Details will instead display the <i>Traffic Event Details</i> screen. For more information, see "How do I view the Event Details screen?" on page 59.	
Nearest POI	Displays the Select POI Category screen. Select the Category, then Search for a POI to navigate to. For further information, see "How do I search for a Point of Interest?" on page 26.	
Avoid Area	Allows you to add an Avoid Area by tapping and dragging the map.	
Un-Avoid Area	Deletes the selected Avoid Area.	
Add to Trip	Adds the location to your multi-stop trip.	
Route	Displays the <i>Route</i> sub-menu from where you can: Set as Start. Sets the location as your departure point. Demonstrate. Starts the route demonstration, demonstrating navigation from your current position or departure point. Stop Demonstration. Stops the route demonstration. Skip Waypoint. Skips the next stop on your multi-stop trip. Show Summary. Displays a summary of your route, including your departure and destination addresses, total distance and total estimated time to your destination. Detour. Detours your route to avoid the next 1, 2, 5, 10 or 20 kilometres or the next 1, 2, 5, 10 or 20 miles.	

How do I avoid an area?

Your Mio can calculate a route that avoids a specified area on the map. Avoid Areas are displayed as shaded areas.



CAUTION If no alternative route around an Avoid Area exists, the route calculation will fail.

CAUTION If your destination is in an Avoid Area, you will be routed into that Avoid Area.

How do I add an Avoid Area?

- 1. Tap the 3D Map or 2D Map screen to display the Map Menu.
- 2. Select Add Avoid Area.
- 3. Tap and drag to set the Avoid Area to the correct size and position. The Avoid Area is added.

How do I delete an Avoid Area?

- 1. Find the Avoid Area that you want to delete.
- 2. Tap the Avoid Area to display the Map Menu.
- 3. Select Un-Avoid Area. The Avoid Area is deleted.

How do I delete all Avoid Areas?



The Saved Information screen will display.

- 1. Tap Delete Avoid Areas.
- 2. When the Caution dialog-box opens, tap Yes to confirm. All Avoid Areas are permanently deleted.

How do I preview a route?

Route demonstration allows you to:

- Preview a route.
- Plan and view a route without a GPS fix, such as when you are inside a building.

The following steps will show you how to preview one route.

1. Select a departure point

If you have a GPS fix, you do not need to select a departure point unless you want the demonstrated route to start elsewhere.

Tap the 3D Map or 2D Map screen at your departure point. a) The Map Menu will display.



b) Tap Route.

The Route submenu will display.

Tap Set As Start. c)

The Map Menu will close, and the selected point is set as your departure point.

2. Select a destination point

Set a destination either by using the address entry wizard or by using the Map Menu:

- a) Locate your destination.
- b) Tap your destination to display the Map Menu.
- Tap Navigate To. c)

The Map Menu will close and the map screen will display the calculated route.

3. Demonstrate the route

Once the route has been determined, you can demonstrate the route by completing the following:

- a) Tap the map screen to display the Map Menu.
- b) Tap Route.

The Route submenu will display.

c) Tap Demonstrate.

The 3D Map screen will display the calculated route in Route Demonstration mode.

How do I view my route statistics?

The Mio provides information on your:

- distance travelled
- average speed
- maximum speed
- time taken for trip
- stationary time.

Trip information is presented in two different ways. These are:

- information for the current trip
- information for all trips to date, or since the tripmeter was last reset.

How do I view statistics on my current route?

The Tripmeter - Current Route screen is used to view statistical information for your current trip.















The Tripmeter - Current Route screen will display.



Complete one of the following:


If you want to	Then
view statistics for your trips to date	tap to display the <i>Tripmeter - Global</i> screen.
reset the tripmeter	 tap Reset. tap Yes to reset. The Tripmeter - Current Route screen will display.

How do I view statistics of my trips to date?

The Tripmeter - Global screen is used to view statistical information for all of your trips to date, or since the trip meter was last reset.



The Tripmeter - Global screen will display.



Complete one of the following:

If you want to	Then
view your trip logs	tap to display the <i>Trip Recorder</i> screen.
view statistics for your current route	tap to display the <i>Tripmeter - Current Route</i> screen.
reset the tripmeter	tap Reset. A Warning dialog box will display.
	tap Yes to reset. The <i>Tripmeter - Global</i> screen will display.

How do I view my trip logs?

Trip Recorder is only available on some models.

The Trip Recorder screen is used to record trip logs of your current trip. The Trip Recorder only records trip logs if you have chosen to record the logs.



The Trip Recorder screen will display.



Complete one of the following:

If you want to	Then
View statistics for your trips to date	tap to display the <i>Tripmeter – Global</i> screen.
stop recording your trip logs	tap Stop Logging.
delete your trip logs	 tap Stop Logging. tap Delete Logs to remove the logs.

How do I use NavPix?


NavPix is only available on some models.

Pictures with a GPS fix are called NavPix and can be used to navigate to the photographed location.

How do I manage my NavPix?

Album management

The albums contain all your NavPix and display them as thumbnails. You can store your NavPix in customizable albums on the Mio internal memory or on your memory card.



	Element	Description	
1	Browse	Displays the Select an Album screen, from where you can select another album.	
2	Сору	Copies selected NavPix from the displayed album to the memory card, or from the memory card to the <i>NavPix</i> album.	
3	Delete	Deletes selected NavPix from the displayed album.	
4	<	Displays the previous screen.	
5	Album title	The title of the album.	
6	NavPix thumbnail	A NavPix thumbnail in the displayed album. To select a NavPix, tap the thumbnail. The NavPix Details screen will display. To select multiple NavPix, tap and hold the first thumbnail, then drag across the other thumbnails. When a NavPix is selected it displays with a green border. Note: If the NavPix has been given a title it will display beneath the NavPix. If the NavPix has not been given a title, the file name of the NavPix will display.	
7	Scroll buttons	Use the scroll buttons to scroll through the NavPix.	
8		Displays if the picture is a NavPix, with embedded GPS coordinates.	

How do I copy NavPix to my memory card?

NavPix can be copied from the albums on your Mio internal memory to your memory card and vice versa.

Note: The first time a NavPix is copied to your memory card, a folder will be created on the memory card called NavPix.

- 1. From the Album screen, tap Browse. The Select an Album screen will display.
- 2 Select the Album you want to view.
- 3. Tap and hold, then drag across the screen to select the NavPix you want to copy. As each NavPix is selected, a green border will appear around it.
 - To cancel a selection, tap and drag over the picture(s) again.
- When you have finished the selection, tap Copy. 4.
- 5. A warning screen will display, asking you to confirm or cancel the procedure. If confirmed, the NavPix will be copied.

How do I delete NavPix from an Album?

NavPix can be deleted from an Album on your Mio internal memory or your memory card.

Note: When a NavPix has been saved as a Favorite destination, you will not delete the Favorite if you subsequently remove the NavPix.

- 1 From the Album screen, tap Browse. The Select an Album screen will display.
- 2. Select the Album you want to view.
- 3. Tap and hold, then drag across the screen to select the NavPix you want to delete. As each NavPix is selected, a green border will appear around it.
 - To cancel a selection, tap and drag across the NavPix again.
- When you have finished the selection, tap Delete.
- A warning screen will display, asking you to confirm or cancel the procedure. If confirmed, the NavPix will be deleted.

Tip: You can also delete a single NavPix via the Photo Details screen.

NavPix management

The NavPix Details screen displays information about your NavPix. Tap a NavPix to display the Photo Details screen.



	Element	Description
1	Thumbnail	A thumbnail of the NavPix.
		Tap to display the NavPix in full-screen.
2	NavPix Title	The title of the NavPix; tap Edit to add a title or edit the existing title.
3	Show on Map	When selected, displays an icon on the map at the location the NavPix was taken.
		Note: Show on map is available only if this is a NavPix with embedded GPS coordinates.
4	<	Tap to return to your album.
5	Time / Date and Location Coordinates	Displays the time and date the NavPix was taken. Displays the GPS coordinates if available.
6	< >	Tap the scroll buttons to scroll through your album.
7	Save	Allows you to save a NavPix to an existing favorite, if GPS coordinates are associated with the NavPix .
8	Edit	Allows you to edit the name of the NavPix using the Keyboard screen.
9	Delete	Deletes a NavPix from the album on your Mio or memory card.
10		Your route will be calculated and displayed on the <i>3D Map</i> screen. Note: This button is only available if this is a NavPix with embedded GPS coordinates.

How do I view a NavPix in full-screen?

From the NavPix Details screen, tap the thumbnail of the NavPix. The NavPix will appear in full-screen.



Note: The icons disappear after a few seconds; tap the screen to have them reappear.

2. Complete the following:

If you want to	Then
zoom into the NavPix	tap .
zoom out of the NavPix	tap [4].
rotate the NavPix	tap 5. The NavPix will rotate 90 degrees anticlockwise each time is tapped; the NavPix is saved at the new angle.
view parts of the NavPix not displayed onscreen	tap and hold the NavPix, then drag across the screen.
return to the NavPix Details screen	tap <
scroll through your NavPix	tap ().

How do I add or edit a NavPix description?















- 1. From the NavPix screen, tap Browse. The Select an Album screen will display.
- 2. Select an album from the list. The Album screen will display.
- 3. Tap a NavPix. The NavPix Details screen will display.
- 4. From the NavPix Details screen, tap Edit. The Keyboard screen will display.
- 5. Tap each character as required. The description will appear at the top of the screen.
- When the description is completed, tap 6. The NavPix Details screen will display, with a new description under the thumbnail.

Note: A description can be added to your NavPix or an existing description can be edited only if you have saved the NavPix as a POI or as a favorite. For more information see "How do I save a NavPix to a favorite?" on page 55 or "How do I save a NavPix to a POI?" on page 56.

How do I navigate to a NavPix?

Your Mio contains preinstalled NavPix that you can navigate to. If you have not yet navigated to a NavPix, three of the preinstalled NavPix will display on the Go To NavPix screen. Otherwise, three of your recently used NavPix are displayed.

Note: To navigate to a NavPix location, either a GPS fix must have been available when the NavPix was taken, or GPS coordinates have been added using MioMore Desktop.

How do I navigate to a recent NavPix?



1. Tap the NavPix you want to navigate to. The Preview screen will display.



2. Tap


Your Mio will calculate the route from your current location. The 3D Map screen will display.

How do I navigate to a NavPix I have downloaded, or was preinstalled?



1. Tap a NavPix.

The NavPix Details screen will display.



2.

Your Mio will calculate the route from your current location. The 3D Map screen will display.

How do I save a NavPix to a favorite?

Note: When a NavPix is saved to an existing favorite, only the images, and not the GPS coordinates, are associated with the favorite.















From the Album screen, select and tap a NavPix. The NavPix Details screen will display.



2. From the NavPix Details screen, tap Assign. The Save Photo screen will display.



If you want to	Then
edit the name of the favorite	tap tap . The Keyboard screen will display. Enter a name for your Favorite, then tap
save the NavPix as a Favorite (when GPS coordinates are associated with a picture)	 tap Save as Favorite and select A new favorite from the list. The NavPix is saved as a new Favorite and the Photo Details screen will display. Note: You cannot save a NavPix as a favorite if GPS coordinates are not available.
save a picture to an address	tap Save as Favorite and select a favorite from the list. The NavPix is saved to a favorite and the Photo Details screen will display.

How do I save a NavPix to a POI?

Note: Only a NavPix with embedded GPS coordinates can be saved as a POI.

















1. From the Album screen, select and tap a NavPix. The NavPix Details screen will display.



2. From the NavPix Details screen, tap Assign. The Save Photo screen will display.



- 3. Tap Save as POI. The Select POI Categories screen will display.
- 4. Complete the following:

If you want to	Then
edit the name of the POI	 tap
save the NavPix as a POI (when GPS coordinates are associated with a picture)	tap Save as POI and select POI Category from the list., then tap Note: You cannot save a NavPix as a favorite if GPS coordinates are not available.
create a new custom POI category and save a NavPix as a POI	 tap A new category to create a custom POI category. The keyboard screen will display. Enter a name for your POI, then tap The Select POI Categories screen will display the new POI category. select the POI Category from the list, then tap

Traffic

Traffic information is only available on some models and in selected countries

Your Mio can receive current traffic information for all main roads and motorways, enabling you to avoid potential delays on your route. Event messages and traffic icons will display as they occur. If an event message obscures your current location, the map will adjust to display both the message and your location.

How does my Mio receive traffic information?

You can receive current traffic information on your Mio via the Mio Traffic cradle using the Traffic Message Channel (TMC) service. The TMC service is subscription-free. The traffic cradle may be sold separately.

The Traffic Message Channel (TMC) broadcasts real-time traffic and weather information via the FM Radio Data System (RDS), FM radio stations transmit TMC data on a cycle of several minutes, with hundreds of events able to be broadcast to TMC receivers, such as the Mio Traffic module.

Traffic status

Your current traffic status is indicated by the color of the TMC icon.

NE and then tap To view your current traffic status from the map screens, tap

The following table describes the three traffic status icons:

Traffic Status	Description
र्च्चाड 🔘	The TMC status is gray if traffic is currently inactive due to one of the following conditions:
	Your Mio or Traffic module is connecting to the TMC service.
	 Your Mio or Traffic module cannot receive TMC data. This may be due to poor radio coverage in the local vicinity.
	You are in a country that is not supported by the Mio Traffic module.
	Tap to display the <i>Traffic Overview</i> screen.
400	The TMC status is orange if one of the following conditions apply:
books 🔍	 You have navigated into a country that is not supported by Mio Traffic, but there are still traffic events listed on the Event List screen.
	 You have separated your Mio from the Mio Traffic module, or the Mio Traffic module is not receiving power but there are still traffic events listed on the Event List screen.
	Tap to display the <i>Traffic Overview</i> screen.
បររ័ថ្ម 🔾	The TMC status is green if your Mio or Traffic module is active and receiving traffic events.
	Tap to display the Traffic Overview screen.

Your traffic status is displayed in more detail on the Traffic System Status screen.

How will I know when a Traffic Event occurs?

Incoming events are handled according to your Traffic preferences. For more information, see "How do I customize Traffic preferences?" on page 72.

When travelling through an area in which you can receive traffic status, your Mio will decode these events and display them on-screen. An icon will display at the event location on the map screens, and an audible warning is given if an event is on your route. Where the extent of an event is a specific distance, the road will be highlighted and arrows will indicate the direction affected



A message will display at the bottom of the screen with the road name, the section of road affected and the type of event that has occurred. The message remains on screen for 8 seconds and is added to the Event List.

How do I view a list of all events on my route?

Your Mio creates a list of events as they are received, which is displayed on the Event List screen. This screen can only be viewed if the TMC icon is green or orange.

From the *Traffic Overview* screen, tap




	Element	Description
	Event description	Displays details of the Event, including: Name of road and direction in which Event is taking place. Location of where Event begins and ends. indicates an Event from a location, to a location. indicates an Event between locations. Type of Event.
2	Event icon	Displays icon to indicate type of event. See page 119 to view list of icons.
3	<	Tap to return to the previous screen.
4		Tap to display the Select event sorting type screen, where you can sort events by distance, road name or age.
5	Position indicator	Displays your position in the Event List screen.
6	Scroll buttons	Allow you to view all events by moving up and down through the list.
7	Event number	Displays the number of events in current list.

How do I view traffic details?

There are several ways to view details of an event received by your Mio.

Choose one of the following:

Location	Option
From any of the screens used to view your route	 Tap the Event message when it appears on screen. The Event Details screen will display.
From the <i>Traffic Overview</i> screen	 Tap The Event List screen will display. Select and tap the event you want to view. The Event Details screen will display.
From the Map Menu	Tap and hold the traffic icon, which displays at the location of the event. The Map View menu will display.
	Tap Show Details. The Event Details screen will display.



	Element	Description
1	Event description	Displays Event details, including: ■ Time Event was received, or last updated. ■ Name of road on which Event is taking place. ■ Location of where Event begins and ends. > indicates an Event from a location, to a location.
		Type of Event.
2	Event icon	Displays icon to indicate type of Event.
3	Detour information	Displays details of detour recommendation, if any. For more information, see "How do I know if a detour is recommended?" on page 61.
4	<	Tap to return to the previous screen.
5	< >	 Tap to view next Event in list. Tap to view previous Event in list.
6	Event number	Displays the number of the event currently displayed and the total number of events in the list.

	Element	Description
7	- ∕ A →	Tap to initiate a new route to avoid the event. Only available if a detour or re-route is available. Note: Un-avoid area is represented by calculated.

How do I know if a detour is recommended?

When a Traffic or Clearance event occurs on your route, a detour will always be recommended. The detour event message will display in the status bar on map screens.

Note: Detours are only recommended for Traffic or Clearance Events on a calculated route.

How do I avoid an event on my route?

From the Traffic Overview screen, tap

- From the Event List screen, tap the event. The Event Details screen will display.
- 2. If a detour has been calculated to avoid an event on your route, is available; tap to accept the new route and avoid the event. The 3D Map screen will display.

How do I cancel a detour around an event on my route?

If you have chosen to avoid an event and a new route has been calculated, you can cancel the detour around the event and return to your original route.

- From the Event List screen, tap the Event you want to un-avoid. The Event Details screen will display.
- 2. Re-route information displays at the bottom of the screen.
 - If a re-route has been calculated, is available; tap to accept the new route. The 3D Map screen will display.

How do I automatically avoid all traffic and clearance events on my route?

To automatically avoid all traffic and clearance events see Traffic preferences on page 78.

Traffic Messages

The Event Details screen displays detour status information.

Detour Not Available messages

If a detour is not available, one of the following messages will display:

Message	Description	
This Event is not locatable	A appoint location for the Event connect he identified	
This clearance is not locatable	A specific location for the Event cannot be identified.	
This Event does not affect your route		
This clearance does not affect your route	The Event is not on the current leg of your journey, or is behind your current position.	
You are avoiding this Event	The Event is not on the current leg of your journey.	
You have accepted this clearance	The Event is not on the current leg of your journey.	
You are too distant to re-route		
You are too distant to accept this clearance	The Event is currently too distant to affect your journey.	
Detour not found	A determine and a solid making and a determine	
Clearance route not found	A detour / re-route could not be calculated.	

Detour recommended messages

If a detour is recommended, one of the following messages will display:

Message	Description
Finding detour Recalculating route	Your Mio is calculating a new route. During calculation, the % complete will display. Note: Exiting this screen before the new route is calculated will cancel the operation.
Detour distance Clearance change	A detour has been calculated. The difference between the distance of your current route and the proposed route is displayed.

What can I customize?

There are various customization options available to enhance your navigation experience.

The Preferences menu screens are accessed by pressing


















- To revisit the previous screen, tap ...

Route Options

You can enhance your navigation experience by modifying aspects of your route and route calculation.

Route Calculation 1/4





If you want to	Then
change the route type	move the Route Type slider towards Fastest time to give high priority to the fastest time when calculating a route.
	move the Route Type slider towards Shortest distance to give high priority to the shortest distance when calculating a route.
	Note: Changing shortest distance over faster time can cause much longer journey time.
change the preference for freeways	move the Preference for Freeways slider towards Less often to use roads other than motorways where possible when calculating a route.
	Note: This option may not completely remove Motorways from a route.
	move the Preference for Freeways slider towards More often to use motorways where possible when calculating a route.

Your preferences are automatically saved.

Road Types 2/4



If you want to	Then
avoid toll roads	select the Toll roads check box in the Avoid column.
receive a warning if your route includes toll roads	select the Toll roads check box in the Warn column. The warning will display at the start of every trip containing a toll road.
avoid unsealed roads	select the Unsealed roads check box in the Avoid column.
receive a warning if your route includes unsealed roads	select the Unsealed roads check box in the Warn column. The warning will display at the start of every trip containing unsealed roads.
avoid ferry routes	select the Ferry routes check box in the Avoid column.
	Note: Selecting Ferry routes does not allow you to travel between continents or even countries.
receive a warning if your route includes ferry routes	select the Ferry routes check box in the Warn column. The warning will display at the start of every trip containing ferry routes.

Your preferences are automatically saved.

Driver Alerts 3/4



If you want to	Then
enable a visual warning if the <i>Main Menu</i> screen is accessed in a moving vehicle	select the Warn me not to operate my Mio while driving check box.
enable a warning chime when travelling at or above a designated speed	select the Alert me when my speed exceeds check box.
select your preferred speed	select your preferred speed from the Speed box.

Your preferences are automatically saved.

Data Recording 4/4



If you want to	Then
record a GPS log of your trips	select the Enable GPS data logging check box.
record mileage that can be imported into MioMore Desktop to create expense reports	select the Enable trip recording check box.

Your preferences are automatically saved.

Map Display

You can change the look and behaviour of the Map screens by customizing the Map Display preferences.

Map Display 1/3









· · · · · · · · · · · · · · · · · · ·	
If you want to	Then
change the map color scheme	select your preferred scheme from the Map Scheme box.
set the screen contrast to automatically adjust	select the Auto day/night option.
improve screen contrast in light or dark conditions	select either the Day or the Night option to manually adjust the contrast.

Your preferences are automatically saved.

Map Display 2/3




Complete the following:

If you want to	Then
enable automatic zooming during navigation	select the Auto-zoom on main map screens check box. If selected, the <i>3D Map</i> screen will automatically zoom in or out, depending on your speed, to allow optimal viewing of your route.
display North at the top of the 2D Map screen	select the Keep North at top of 2D Map screen check box. Note: If not selected, the direction you are travelling in will display at the top of the 2D Map screen.
display "no entry" icons on "no entry" roads on the 2D Map and 3D Map screens	select the Show no-entry road signs check box.

Your preferences are automatically saved.

Select Map 3/3





Complete the following:

If you want to	Then
use maps from a different continent	select a different continent from the maps you are currently using. When selected, the maps for the new continent will load and the <i>3D Map</i> screen will display.

Your preferences are automatically saved.

Map POIs

Points of Interest (POIs) are grouped into categories. You may choose to either display (or hide) icons of all POI categories on the map screens, or only display the icons from selected categories.

For example, you may only be interested in entertainment venues and want to disable other categories such as schools.





Complete the following:

If you want to	Then
display all POI icons (ie, icons from all categories)	Tap Turn All On .
display no POI icons	Tap Turn All Off.
select a specific POI category icon for display on the map screens	select the required POI category checkbox; repeat until all required categories are selected.

Your preferences are automatically saved.

Volume









If you want to	Then
increase or decrease the volume	move the Volume slider towards High to increase the volume.
	move the Volume slider towards Low to decrease the volume.
hear a tone when you tap the touch screen	select the Audio check box.
hear keyboard characters spoken to you	select the Speak keyboard letters check box.

Your preferences are automatically saved.

Screen









Complete the following:

If you want to	Then
change the screen	move the Screen Brightness slider towards Bright to increase screen brightness.
brightness	move the Screen Brightness slider towards Dim to decrease screen brightness.
	Warning: Your Mio can heat up when the <i>Brightness</i> scale is set above 70% - i.e., when more than seven rectangles are colored - therefore, use lower brightness whenever acceptable.

POI Alerts

The POI Alert preferences allow you to set a warning chime and/or visual warning to Point of Interest categories that you have installed via MioMore Desktop (Custom POIs). You may also be able to set warnings to certain POI categories that were preinstalled on your Mio or available by subscription, such as Safety Cameras.


If you have a route set, the warnings will occur when you are a certain distance (set by the Warning Distance preference) from the POI on your route.

If you do not have a route set, the warnings will occur when you are in the vicinity of the POI.









1. Tap a custom POI category. The activation preferences for the selected category will display.



2. Complete the following:

If you want to	Then
display locations in this category on the map	select the Display on the map check box.
enable a warning chime when locations in this category are in close proximity	select the With an audible alert check box.
enable a visual warning when locations in this category are in close proximity	select the With a visual alert check box.
select the distance at which the warnings will activate	move the Warning distance slider to select the distance at which the warnings will activate.

GPS

GPS Status

Signals are transmitted by Global Positioning System (GPS) satelites orbiting the Earth. The GPS Status screen provides a visual representation of the information being received.

Latitude and longitude are displayed, along with ground speed and the heading in degrees. The strength of each satelite is displayed on a bar chart.





The satelites available from your current position are shown as gray, red and green colored bars:

Bar color	Description
Gray	No signal.
Red	A valid signal, but not being used to fix your position.
Green	A valid signal being used to fix your position.

Resetting your GPS fix

Occasionally, the GPS fix may need to be reset. This may occur if the receiver has been transported a long distance since last being used; for example, to a different country, and is still trying to establish the previous position.

Complete the following:

If you want to	Then
reset the GPS	tap Reset GPS.

Setting your GPS mode



Complete the following:

If you want to	Then
use GPS	select the Normal option.
use WAAS	select the WAAS (only available in USA) option.
use EGNOS	select the EGNOS (only available in Europe) option.

WAAS - Wide Area Augmentation System is a navigation system developed for civil aviation by the Federal Aviation Administration (FAA), a division of the United States Department of Transportation (DOT).

EGNOS - European Geostationary Navigation Overlay Service is a satelite based augmentation system (SBAS) under development by the European Space Agency, the European Commission and EUROCONTROL.

Tip: You should only change the default setting if you are experiencing poor GPS performance.

Language



Complete the following:

If you want to	Then
enable voice guidance	select the Enable voice guidance check box.
change the on-screen language	select your preferred language from the Language box and tap Yes.
	Your language preference is saved and the map screen is displayed.
change the voice scheme	select your preferred voice scheme from the Voice Guidance box.
	Note: Only voice schemes that are compatible with the chosen language are displayed.

Traffic

You can view your current traffic system status and change options by customizing the traffic preferences.

Traffic System Status





From the Traffic Overview screen:





The Tuner section displays the name and frequency of the radio station currently being used to receive traffic event information. A bar shows the strength of the traffic signal being received; the more green bars, the stronger the signal.

Complete the following:

If you want to	Then
change your preferred radio station	select your preferred radio station from the Preferred Station dropdown.

Traffic Event Notification



OR

From the Traffic Overview screen:



Complete the following:

If you want to	Then
turn on/ off traffic event notification	select the Notify me about nearby traffic events check box to receive traffic event notification.
	clear the Notify me about nearby traffic events check box to turn off traffic event notification.
	Note: Event icons will still display on the 3D and 2D Map screens.
be notified about events that affect your current route	select the Only notify me about events on my route check box.
be notified only when a detour is recommended	select the Only notify me if a detour is recommended check box
automatically accept recommended detours and have a new route calculated	select the Automatically accept recommended detours check box.

Your preferences are automatically saved.

Select event sorting type

From the Traffic Overview screen:



Age

Complete one the following:

Only show events on my route

✓ Select event sorting type ✓

If you want to	Then
ii you want to	IIIGII
sort events by distance	select the Distance check box.
sort events by road name	select the Road name check box.
sort events by age	select the Age check box
only see events that occur on your route	select the Only show events on my route check box.

Your preferences are automatically saved.

Power



The **Battery Status** bar shows the percentage of power left in the Mio battery; the words **External Power** will display when the battery is charging from an external power source.

To charge the battery, see "

How do I monitor the battery status?" on page 13.

Complete the following:

If you want to	Then
change the time to elapse before turning off, when using battery power	tap the on battery power box and select a time to elapse before turning off; select Never for the Mio to never automatically turn off. Note: If you select Never, your Mio will turn off if the power is very low.
change the time to elapse before turning off, when using external power	tap the on external power box and select a time to elapse before turning off; select Never for the Mio to never automatically turn off.

Keyboard



Complete the following:

If you want to	Then
use an alphabetic keyboard for entering information	select the Use alphabetic type (a, b, c) option.
use a QWERTY keyboard for entering information	select the Use QWERTY type option.
use a keypad-type keyboard (predictive text) when searching for an address	select the Use keypad type (abc, def) for address searches check box.

Your preferences are automatically saved.

How does predictive text (abc, def...) work?

Predictive text allows addresses to be searched by a single key-press for each letter, as opposed to the multiple key-presses. As you enter a letter of an address, your Mio will compare all possible combinations against the maps you have installed and determine which address you intended to type.

For example:

To enter London, tap JKL MNO MNO DEF MNO MNO .

Your Mio will compare all possible combinations and display **London** as a search result. You can add further letters to narrow the search.

Units

You can change the units used by your Mio by customizing the measurements preferences.

Units 1/2



Complete the following:

If you want to	Then
change the time format	select either the 12 hour or 24 hour option
change the distance units ¹	select your preferred distance unit type from the Distance Units options.

¹ Only available when AU English, UK English or US English language is selected.

Units 2/2



Complete the following:

If you want to	Then
change the latitude, longitude position format	select either the Decimal degrees or the Degrees, minutes and seconds option.

Start-up



Complete the following:

If you want to	Then
show the Tutorial when you turn on your Mio	select the Show the Tutorial checkbox.
show the Language Selection screen when you turn on your Mio	select the Show the Language Selection screen checkbox.

Saved Info



Complete the following:

If you want to	Then
delete recent locations	tap Delete Recent Locations.
delete favorites	tap Delete Favorite Destinations.
delete avoid areas	tap Delete Avoid Areas.
restore factory default settings	tap Restore Factory Defaults.
	Note: The Restore Factory Defaults option does not delete recent locations or saved favorite destinations.
clear all settings; for example, for use in a rental car	complete all of the above.

When the warning dialog box displays, tap Yes.

Tutorial

The Tutorial displays when you turn your Mio on, unless you have cleared the Show tutorial on start-up check box.

You can view the Tutorial at any other time:




- To prevent the Tutorial from displaying again on startup, clear the Show on start-up check box to clear it.
- To move forward through the *Tutorial* screens, tap
- To revisit the previous screen, tap

About



This preference contains copyright and trademark information.

Shop Demo



Complete the following:

If you want to	Then
•	tap Shop Demo on the preference screen. After a short delay, the route will be demonstration will navigate between your first and second favorite.

What is MioMore Desktop?

MioMore Desktop is a suite of tools you can use to access greater functionality and product information via your computer.

MioMore Desktop allows you to:

- obtain software updates
- search online for local POIs
- manage maps
- manage custom POIs
- manage safety camera subscriptions
- report trip mileage
- transfer pictures from your Mio using Photo Album
- browse the Mio website for special offers.

Can I use MioMore Desktop with my computer?

Ensure your computer has the following *minimum* system requirements before installing MioMore Desktop:

- IBM compatible PC.
- Microsoft® XP SP2 or later (XP MCE, XP x64, Vista x64 not supported),
- Internet Explorer 6 or higher,
- DVD or CD drive,
- USB port,
- Internet connection for activation.

Note: For Windows XP users, Microsoft .NET 2.0 will be installed on your computer as part of the installation of MioMore Desktop.

How do I install a map for the first time?

The most common task performed using MioMore Desktop is the installation of a new map to your Mio internal memory or memory card. Complete the following procedures:

Step	Action
1	Install MioMore Desktop on your computer (see "How do I install MioMore Desktop onto my computer?" on page 91).
2	Check for software updates for MioMore Desktop on your Mio (see "How do I keep MioMore Desktop up-to-date?" on page 93).
3	Install one or more maps on your Mio (see "How do I install maps onto my Mio?" on page 97).

How do I install MioMore Desktop onto my computer?

Note: Before you begin:

Ensure that your computer meets the minimum system requirements for MioMore Desktop, especially:

i. Ensure that Internet Explorer 6 or higher is installed on your computer before you install MioMore Desktop, even if it is not your default browser

- ii. Windows XP users, ensure that Windows XP Service Pack 2 or higher has been applied before you install MioMore Desktop.
- 1. Close all programs on your computer.
- 2. Insert the MioMore Desktop Application Installer DVD into your computer DVD drive. The MioMore Desktop installer will start.

If your computer does not automatically launch the DVD, start the installation manually: Start → Run.

Type D:\Install.exe where "D" is the letter assigned to your DVD drive, then click OK.



- 3 Select your preferred language for MioMore Desktop.
- 4 Click Install MioMore Desktop.
- 5. Follow the screen prompts to install MioMore Desktop:
 - Review and accept the Licence Agreement for MioMore Desktop when prompted.
 - Select a destination folder for MioMore Desktop when prompted.
 - When the installation has finished, click Finish. MioMore Desktop will open.
- 6. If prompted to connect your Mio to your computer, complete the following:
 - Plug the large end of the USB cable directly into a USB port on your computer (not a USB hub) and plug the small end into the **USB Socket** (on the bottom of your Mio.

Tip: Where possible, plug the USB cable into a USB port at the back of your computer.

Push the **Power Switch** to the middle position, to turn on your Mio. The following screen will display on your Mio.




If prompted to update your Mio software, follow the on-screen prompts.

You are now ready to use MioMore Desktop to install maps to your Mio.

MioMore Desktop features

Depending on your Mio model, certain MioMore Desktop features may not be available.

Start → All Programs → Mio → MioMore Desktop



	Element	Description
1	Menu bar	Menus that provide access to basic MioMore Desktop functionality.
2	Mio online	Displays the Mio website.
3	Mio Connect	Application used to search and install local POIs for a route.
4	My Maps	Application used to install and manage maps.
5	My Subscription	Information on your current subscriptions, including safety camera subscription.
6	Photo Album	Application used to transfer NavPix from your Mio to your computer. The software enables you to: Manage albums Copy Delete Move NavPix or albums between the NavPix library on your Mio and the NavPix library on your computer.
7	Image Search	Search and download NavPix from a website. Note: This feature is powered by Flickr.
8	Custom POIs	Application that allows you to import custom POIs.
9	Mileage Reporter	Uses data recorder on your Mio allowing you generate expense reports on the mileage/ estimated fuel usage of your trip.
10	Voice Transfers	Application that allows you to install or remove voice files from your Mio.
11	Activation	Application used to activate a product key when you purchase a subscription or maps.

How do I keep MioMore Desktop up-to-date?

We recommend that you regularly use MioMore Desktop to check the Mio server for MioMore Desktop software updates.

How do I update MioMore Desktop?

Start → All Programs → Mio → MioMore Desktop → Tools → Options → General

Select Auto check for updates checkbox.

When you select this option, every time you access MioMore Desktop, the latest service packs and bug fixes if available are downloaded from the Mio server and applied to your Mio.

Note: Updating software is different from upgrading software. To upgrade MioMore Desktop, you must first purchase a new version of MioMore Desktop from a retailer, then install it on your Mio.

MioMore Desktop Preferences

Tools → Options → General

Complete one of the following:

If you want to	Then
upgrade from a previous version of MioMore Desktop	follow the instructions in the <i>Installation Guide</i> or <i>Upgrade Guide</i> that came with your MioMore Desktop upgrade.
change the MioMore Desktop measurement to metric units	Select the Use metric units check box.
change the MioMore Desktop measurement to decimals	Select the Decimal degrees check box.

MioMore Connect

MioMore Connect is a MioMore Desktop application that allows you to search and install local POI information from your computer to your Mio.

Tip: Before you begin, ensure your Mio is correctly plugged into your computer: Plug the large end of the USB cable directly into a USB port on your computer (not a USB hub); plug the small end into on the side of your Mio.

Start → All Programs → Mio → MioMore Desktop → MioMore Connect



	Element	Description
1	Search location	Displays search fields
2	Globe	Displays selected place name results.
3	My saved locations	Displays a list of POIs that are installed on your Mio.

How do I search for a POI using MioMore Connect?

- 1. From the country drop down box, select a Country.
- 2. From the Region/State drop down box select a Region/State if required.
- In the Place name box, enter the first few letters of a city and then select your preference. 3.
- Click Continue. 4 The Available Services page will display.
- 5. Select your preferred search service. The selected services page will display.

Note: Depending on the country you are navigating, the available search services may vary.

6. Enter your search criteria and then click Search. The Select search method page will display.

Note: For some countries you are required to accept the terms of use.

Select your preferred search method and then click Search. 7. A list of search results will display.

How do I install POIs from my computer to my Mio?

- 1. Perform step 1 to 8 of "How do I search for POI using Mio Connect.
- 2. Click Add to Mio next to the POI you want to install.
- 3. Repeat step 1 and 2 to install more POIs to your Mio.

Note: You can install a maximum of 200 POIs on your Mio via Mio Connect.

How do I delete a POI from my Mio?


- 1. From My saved locations select a checkbox of the POI you want to delete.
- 2. Click **Delete Selected**. The POI is deleted from your Mio.
- 3. Repeat step 1 and 2 to delete more POIs to your Mio.

Note: To delete all the POIs installed on your Mio, select the Select All check box and then click Delete Selected.

My Maps

The My Map application allows you to install new maps, remove maps from your device and purchase new maps.

Start → All Programs → Mio → MioMore Desktop → My Maps



	Element	Description
1	Zoom In	Click to zoom in.
2	Continent	A drop down list of continents that have maps available for your Mio.
3	Map Source	A list of maps on the DVD or available for purchase via the Mio store website.
4	My Mio	A list of maps installed on your Mio.
5	Zoom Out	Click to zoom out.
6	Find City	Click to open the Find City window to search for a city or town.
7	Globe	A map of the world or a continent selected indicating the maps: on the current DVD, installed on your Mio or memory card, or available from Mio.

How do I install maps onto my Mio?

Your Mio comes with one or more pre-activated maps.

You can install maps from the enclosed DVDs to a memory card or your Mio internal memory: however you may need to purchase a Map Product Key to activate the maps.

Which map should I install?

If you are not sure which map contains the town or city that you want to install, you can use the Find City window to identify the correct map. For more information, see "How do I know which map contains a particular city or town?" on page 99.

How do I install maps from DVD?

- Open MioMore Desktop, if it is not already open: Start → All Programs → Mio → MioMore Desktop
- 2 Click Mv Maps. The My Maps application will display.
- 3. Insert a Map DVD into your computer DVD drive.
 - The maps that are already installed on your Mio are green.
 - The maps that are unlocked and ready to be installed to your Mio are yellow.
 - The maps that require activation before being installed to your Mio are red.
 - The maps that are available for purchase from Mio are blue.

Note: If your computer opens Windows Explorer when the DVD is inserted, close the Windows Explorer window,



Complete the following:

If the map to be installed is	Then
yellow	go to step 7.
red	the map needs to be activated via the Internet before it can be installed; continue to step 5.

- 5. If you connect to the Internet via a dial-up connection, connect to the Internet now.
- 6. Follow the prompts to activate your Map Product Key, including:
 - Enter the Map Product Key when prompted.



- Your computer will connect to the Internet and activate your Map Product Key.
- When activation has completed, the map will change color to amber; continue to step 7.



7. Click the map you want to install to your Mio.

The map will change color to yellow to indicate it has been selected.

To deselect a map, click the map again.

Note: You may need to install multiple maps to cover the required geographical area.

8. Complete the following:

If you want to	Then
select an yellow map	go back to step 7.
select a red map	the map needs to be activated via the Internet before it can be installed; go back to step 5.
install the selected maps to your Mio	continue to step 9.

Select the destination media for the selected maps, then click Transfer Now.
 The selected maps will be installed and change color to green.



10. To use your Mio, disconnect the USB cable.



WARNING Do not disconnect the USB cable from the Mio USB Socket until the installed map or maps have changed color to green.

How do I remove maps from my Mio?

- 1. Click My Maps.
 - The My Maps application will display.
- 2. From the My Mio panel, select the check box next to the map you want to remove.
- 3. Click Remove Maps to remove the selected maps.
- Confirm that you want to remove the selected map when prompted. 4. The map is removed from your Mio.

How do I know which map contains a particular city or town?

Use the Find City window to find the map that contains a particular city or town.

- 1. Click My Maps.
 - The My Maps application will display.
- 2. On the My Maps panel, click Find City. The Search for City window will open.



- Type the name of the city or town in the City Name field. 3. The list of available cities will reduce to match your search.
- Select the name of the city or town, then click **Show on Map**. 4. The globe will rotate to centre on the selected city or town.

My Map Preferences

Tools → Options → My Maps

If you want to	Then
show longitude and latitude lines	select the Show Graticule check box. The longitude and latitude lines will display.
	Note: To view the latitude and longitude, you need to have a region selected.

What is a Major Road Network map?

Continuous continental navigation

Navigation between particular countries is not available on all models.

Major Road Network maps allow you to seamlessly navigate between installed maps without installing maps of all regions along your route. Each Major Road Network map covers a large area, such as North Amaerica, and contains main roads that connect cities and towns. You can select a road or Point of Interest on the Major Road Network map as your departure point or destination.

All Major Road Network maps:

- contain roads and ferry connections of high national and international importance.
- use less memory than would be necessary to install all equivalent detailed maps.
- exclude smaller roads and have a reduced level of geographical detail.

How do I install or reinstall a Major Road Network map?

Major Road Network maps can be installed to a new memory card or reinstalled to your Mio the same way detailed maps are installed. For more information, see "How do I install maps from DVD?" on page 97.

Photo Album

Depending on your Mio model, certain Photo Album features may not be available.

Photo Album is a MioMore Desktop application which allows you to copy, delete or move pictures or albums between the **NavPix** library on your Mio and the **NavPix** library on your computer.

Start → All Programs → Mio → MioMore Desktop → Photo Album



	Element	Description
1	NavPix menu	Gives access to Photo Album functionality.
2	Desktop albums	Displays a list of all albums stored in the NavPix library on your computer.
		Click an album to display its contents in the Album display area.
		Click the View all pictures button to display all pictures stored in the NavPix library on your computer.
3	My Mio albums	Displays a list of albums stored on the Mio internal memory and on the memory card if one is inserted.
		Click an album to display its contents in the Album display area.
4	Album display area	Displays thumbnails of pictures in the selected album.
5	Selected picture	When a thumbnail is selected it displays with a blue border.
6	Search	Type to search for a NavPix by name.
7	Toolbar	When a picture is selected, the icons which can be used will be active.

Toolbar



The following options are available on the toolbar:

	Button	Description
1	Create new album	Click to create a new album in the NavPix library you are viewing.
2	Rotate left	Rotates the selected NavPix 90° to the left.
3	Rotate right	Rotates the selected NavPix 90° to the right.
4	Transfer to your Mio or Transfer to your computer	 If you are viewing NavPix in the NavPix library on your computer, this will display as Transfer to your Mio. Click to transfer the selected NavPix to your Mio. If you are viewing NavPix in the Mio library this will display as Transfer to your computer. Click to transfer the selected NavPix to the NavPix library on your computer.
5	Import NavPix	Imports NavPix from your computer to the NavPix library on your computer.
6	View details	Click to view the selected NavPix and edit NavPix details, including: NavPix name latitude longitude description.
7	Export to disk	Click to save NavPix to your computer or a network drive.
8	Delete NavPix	Click to delete the selected NavPix.

How do Luse Photo Album?

How do I transfer pictures from Photo Album to my Mio?

You can transfer pictures from your computer to your Mio. You can import any JPEG (.jpg) into Photo Album, add or edit GPS information, and then copy the picture to your Mio.

- From the **Toolbar** section, select **Import NavPix**.
 The *Open* dialog box will display.
- Navigate to select a NavPix from an album on your computer and click Open. Thumbnails of the NavPix will display in the Album display area.

Note: You can also drag and drop a NavPix from an album on your computer to an Album on your MioMore Desktop.

 Either click and drag the required NavPix to an album in the Desktop albums section, or click the Transfer to your computer icon on the toolbar.

Note: If you have transferred a NavPix with GPS coordinates you can then navigate to where the picture was taken.

How can I view and edit pictures or albums on my computer?

If you want to	Then
rotate a picture to left	select the picture from the Album display area.
	click Rotate left on the toolbar.
rotate a picture to right	 select the picture from the Album display area.
, ,	click Rotate Right on the toolbar.
view the picture details	 select the picture from the Album display area.
·	 right click and select View Details or click View Details on the toolbar.
edit GPS information	 select the picture from the Album display area.
	 click on the picture or click View Details on the toolbar.
	Following information will display:
	Name
	Latitude and Longitude Description
	·
	Edit the details you want to modify.
	Click OK to save the changes.
delete a picture	 select the picture from the Album display area.
-	 right click and select Delete or click Deletes on the toolbar.

What else can I do with pictures and albums on my computer?

From the NavPix library on your computer, you can:

- add a picture to another album
- remove pictures from an album
- view and edit details of a selected picture
- upload pictures to Flickr™
- export to disk
- export pictures to Google Earth™
- search for pictures
- view all pictures in the library

If you want to	Then
add a picture to another album	 in the Desktop albums section, select the album containing the NavPix you want to include in another album select the NavPix then drag it to the other album.
	Note: The selected NavPix is included in the new album, but is not moved, i.e., one instance of the NavPix in the library may be included in multiple albums.
remove a picture from an album	 in the Desktop albums section, select the album containing the NavPix you want to remove select the NavPix, right click and select Remove from album. Note: Click the Delete icon on the toolbar if you want to delete the NavPix from all albums.
view and edit picture details	 select the picture then click the View Details icon on the toolbar. edit the fields as required.
upload picture to the Flickr website	 in the Desktop albums section, select the album containing the NavPix you want to upload to the Flickr website. select the NavPix, right click and then select Upload to Flickr. Note: You need a Flickr account to upload NavPix. To create a Flickr account visit www.flickr.com
save a picture to your computer	 select the picture from the Album display area. right click and select Export to disk or click Export to disk on the toolbar. Navigate to an album on your computer where you want to save the NavPix.
export to Google Earth TM (only NavPix with GPS coordinates can be exported to Google Earth)	 in the Desktop albums section, select the album containing the picture you want to export to Google Earth. select the NavPix, right click and then select Export to Google Earth. Navigate to a folder on your computer to save the file and then open in Google earth. Note: You need to install the Google Earth software on your computer to be able to view the file you have created. You can download Google Earth from earth.google.com.
search for other NavPix	You can search for other NavPix near the longitude and latitude of your NavPix using Flickr.
view all pictures in the library	click the View all pictures button at the bottom of the Desktop album section.

Photo Album Preferences

Tools → Options → Photo Album

Complete one of the following:


If you want to	Then
change your NavPix location on your computer	 click Change. The Save As dialog box will open. select a location for your NavPix library. click Save. The warning message will display and you will be prompted to confirm your action. Your NavPix library is moved to the new location.
receive a warning message before deleting an image from your device	select Warn me when permanently deleting an image from my device checkbox.
receive a warning message before deleting an image from your NavPix library	select Warn me when permanently deleting an image from my library checkbox.

Image Search

Depending on your Mio model, certain MioMore Desktop features may not be available.

Image Search is a MioMore Desktop application powered by Flickr™ allowing you to download photos and import them to Photo Album.

Start → All Programs → Mio → MioMore Desktop → Image Search



How do I download NavPix from the internet?

- 1. In the **Description** field enter a search description for the image you are looking for.
- 2. Select one of the Sort by options.
- 3. Click Search. Thumbnails of the NavPix will display in the NavPix display area.

Note: You can narrow your search by selecting the Advance Search check box and then selecting a city from the drop down list or by entering longitude and latitude details.

How do I import NavPix to Photo Album?

- 1. From the NavPix display area select a picture or group of pictures you want to upload to your Photo Album.
- 2. Right click and select Import to Photo Album. A new album is created in the **Desktop album** section of Photo Album.


Note: For more information, see "How do I use Photo Album?" on page 103.

Mileage Reporter

Mileage Reporter is only available for some models.

Mileage Reporter is a MioMore Desktop feature that allows you to create expense reports (.csv format) based on the mileage and estimated fuel usage recorded by your Mio.

Start → All Programs → Mio → MioMore Desktop → Mileage Reporter



	Element	Description
1	Timeframe specifies the time for which the mileage report will be created.	
		 Select Show All to include all recorded mileage.
2	Report panel	displays your trip logs.
3	Fuel	 Select to include the amount of fuel (estimate) used for the mileage recorded. If selected, specify the number of miles travelled per gallon, or kilometres travelled per litre.
4	Report data buttons	click to input report data from your Mio or export to a report (.csv).

To set the trip recording preference on your Mio, see "Data Recording" on page 67.

How do I input my trip data?

- 1. Select Show All in the Timeframe section.
- 2. Select the Calculate fuel check box and enter the fuel consumption.
- Click Load from Device on the Report data button section. The Transfer Log progress bar will display.

All your trip logs can now be viewed in the Report panel section.

How do I export a mileage report?

- Select a trip log from the report panel section. 1.
- 2. Click Export report on the Report data button section. The open dialog box will open.
- Select the file from your local or network drive, enter a name for your mileage report and then click Save. 3.

Note: Mileage report is saved in .csv format.

You can view your mileage report by clicking on the file.

How do I delete travel logs from my Mio?

- 1. Select a trip log from the report panel section.
- Click **Delete from device** on the *Report data button* section. 2.
- 3. Click Yes to delete all travel logs.

Mileage Reporter preferences

Tools → Options → Mileage Reporter

Complete one of the following:

If you want to	Then
receive a warning when mileage logs are deleted from your device	Select the Warn me when deleting all log files from my Mio checkbox.
calculate fuel economy preference by Distance per volume	select the Distance per volume option.
calculate fuel economy preference by Volume per distance	select the Volume per distance option.

My subscriptions

Safety camera information is only available for selected countries.

Your Mio contains pre-loaded safety camera information. To subscribe to current Mio safety camera information, use the enclosed DVD to install MioMore Desktop software on your computer.

For the latest safety camera coverage, to subscribe to safety camera information and to see our latest offers, visit www.Mio.com.

Each country has a colored circle indicating the status of your subscription.

Alerts

Safety Camera alerts can be set to enable a warning sound or visual warning when on your route (see "POI Alerts" on page 74).

How do I install Safety Camera information?

Complete the following steps to install safety camera information on your Mio.

- 1. Purchase a subscription.
- Activate your subscription.

How do I know which Safety Camera information is available?

Start → All Programs → Mio → MioMore Desktop → My Subscriptions

- 1. From the Available Subscription section, select the country for which you want to purchase the subscription.
- 2. Left click and select Activate my subscription.

The Activation window will display.

Note: Subscriptions are available only for those countries for which you have purchased maps.

3. Enter a product key and follow the prompts to activate your subscription.

Purchase a Subscription

 To purchase a subscription to safety camera information, on the Subscriptions menu, select the country for which you want to purchase the safety camera and then select Purchase an activation key from the Mio store.

The Mio Store website will open.

Follow the prompts to purchase your subscription.

A product key will be sent to you via email when you have subscribed. You will need to use this product key to activate your subscription.

Activate your Subscription

Start → All Programs → Mio → MioMore Desktop

- 1. From Available Subscriptions section, select the country for which you want to activate the safety camera.
- 2. Right click and select Activate my subscription. The Activation window will display.



- 3. Enter the subscription product key in the **Product Key** field.
- 4. Click Continue. Follow the prompts to update your subscription.

Your software will update automatically.

How do I update Safety Camera information on my Mio?

Start → All Programs → Mio → MioMore Desktop → My Subscription

My Mio section will display a list of subscriptions already installed on your device.

Icon	Description		
red	Expired subscriptions.		
	right click to purchase a new subscription.		
Yellow	Available subscriptions.		
	right click to update and purchase new subscription.		
green	Active subscriptions.		
	Note: No updates are available for these subscriptions.		


Custom POIs

Custom POI feature is only available for some models.

The Custom POI application allows you to create or import your own POI files. These are called custom POIs. Unlike preinstalled POIs, custom POIs can be removed from your Mio and can have audio as well as visual alerts associated to them.

How do I install custom Points of Interest?

Start → All Programs → Mio → MioMore Desktop → Custom POIs



Note: Various POI files are available for download free or by subscription from third-party websites². Ensure that downloaded files are in .csv (Comma Separated Values) format.

- In the Add new POIs section, click Browse to select a source file. The open dialog box will open.
- 2. Select the file from your local or network drive, then click **Open**.
- 3. From the POI Category section:

 If you want to ...
 Then ...

 use an existing custom POI category
 select the Existing Category option, then select a type from the drop down list...

 create a new custom POI category
 select the New Category option, then type a name for the POI category.

² Mio is not responsible for the content or accuracy of the information or the reliability or availability of these websites. The use of information regarding safety camera locations may be subject to local laws in the country of use. You are responsible for checking that you can use the information in your country or in the country where the information will be used.

4. Complete the following:

If you want to	Then		
select an icon to display on the map screens for POIs of the	Click Browse to select the icon file from your local or network drive. When you have located the icon file, select it and click Open .		
category	The icon file must be a bitmap (.bmp) graphic with a minimum size of 6x6 pixels and a maximum size of 32x32 pixels.		
	Note: If you do not select a custom icon, a default icon will display.		
enable a visual warning when a POI of this category is in close proximity	select the Visual alert check box.		
enable a warning sound when a POI of this category is in close proximity	select the Audio alert check box.		
select the distance from a POI of	select the distance from the Distance box.		
this category at which the visual warning should display or the warning chime should sound	Note: To change the units used to measure distance for this POI category, from the tools menu click on options and from the general option select Use metric units check box.		
select a custom sound alert file to	Either select a sound file from the list, or		
play when a POI of this category is in close proximity	Click Add to select a sound file (.WAV format) from your local or network drive. When you have located the file, select it and click Open.		
	Note: If you do not select a custom sound file, a default sound alert will play.		

5. Click on Add to device button to add the POI to your Mio.

Note: Each POI file corresponds to a POI category; for example, Hotels .csv will be listed in your Mio as the Hotels category.

How do I delete a Custom POI File from my Mio?

- On the Installed POIs section click Delete next to the file name.
 The file is removed from the list, but is not yet deleted.
- 2. Accept the warning message. The selected file is deleted.

Voice Transfer

The Voice Transfer application is part of MioMore Desktop and allows you to install or remove voice files.

Voice files take up space on your Mio's internal memory. If you do not use a voice file, you can remove it to free up space. You can later reinstall it to your Mio if required.

Start → All Programs → Mio → MioMore Desktop → Voice Transfer

How do I install a voice file?

In the Available voice files section, select the voice file you would like to install, then click Install selected voices.

How do I remove a voice file?

In the Available voice files section, select the voice file you would like to remove, then click Remove selected voices.

PIN Security

PIN Security is a feature which allows you to set a PIN on your Mio. The PIN will disable your Mio in the event of theft

To set a PIN you must first register your Mio with the Mio server.

How do I register my Mio and set a PIN?

Tools → PIN Security

The PIN Registration screen will display.



- 1. Click Register now and follow the prompts to complete the registration form online.
- 2. When Registration is complete, return to the PIN screen and click I have registered my Mio. The PIN Security screen displays.
- 3. In the User Name and Password fields, enter the Username and Password that you entered when registering online.
- 4. In the PIN field, enter the PIN you want to assign to your Mio.

Note: Your PIN must be between three and eight numerical digits.

Click OK. The PIN for your Mio has been set.

Note: The Enter your PIN screen will now display on your Mio when you turn your Mio on, or once every 24 hours.

How do I remove the PIN from my Mio?

Tools → PIN Security

- In the User Name and Password fields, enter the username and password that you entered when registering online.
- 2. Leave the PIN field blank.
- 3 Click OK

The PIN is removed and your Mio will no longer require you to enter a PIN.

What if I forget the PIN for my Mio?

Tools → PIN Security

- In the User Name and Password fields, enter the username and password that you entered when registering online.
- 2. In the PIN field, enter a new PIN you want to assign to your Mio.

Note: Your PIN must be between three and eight numerical digits.

Click OK. 3.

The PIN for your Mio has been reset.

How do I backup my Mio?



You can save backups of the following information, and later restore them to your Mio:

- Favorites and My Home
- Preferences, including Point of Interest and NavPix preferences
- Multi-stop trips
- Recent locations.

How do I Backup my Mio?

- 1. Tools → Backup Restore The Backup & Restore window will open.
- 2. Click Create new.

The Create new backup window will display.

- Select the data you would like to backup, then enter a description for the backup in the **Description** field. 3.
- 4. Click OK.

The New Backup window will close and your backup will be saved to your computer. The backup will be listed on the Backup & Restore window.

How do I Restore a Backup to my Mio?

- 1. Tools → Backup Restore The Backup & Restore window will open.
- Select the backup from the list, then click Restore, then click OK. The backup will be restored to your Mio.

How do I Delete a Backup?

- Tools → Backup Restore 1. The Backup & Restore window will open.
- 2. Select from the list the backup to delete.
- Click Delete, then click OK. 3. The backup is deleted.

Reference

Point of Interest categories

Icon	Description	Icon	Description
*	Airline Access	★	Airport
*	Amusement Park	8	Arts or Cultural Centre
\$	Bank	7	Beach
1	Boat Ramp	1	Breakdown Service, Car Repair Facility
A	Building	A	Camping Ground
88	Car Dealer	-	Caravan Park, Trailer Park
S	Cash Dispenser	® ®	Casino
	Centre of Settlement	*	Church
® ≥	Cinema		City Centre
÷ x abc	College or University	⊎i	Company
1,1	Concert Hall, Music Centre, Opera		Convention Centre, Exhibition Centre
Ħ	Courthouse	€	Cultural Centre
n*	Dentist	٤ ٠	Doctor
ď₩	Drive-Through Bottle Shop	上	Embassy
+	Emergency Medical Service		Ferry Terminal
<u>*</u>	Fire Station		Frontier Crossing
	General POI	نا	Golf course
	Government Office	+	Hospital/Polyclinic
	Hotel or Motel		Ice Skating Rink
Ψ	Important Tourist Attraction	$\langle \overset{\bullet}{\alpha}$	Leisure Centre, Sports Centre
₽	Library		Military Cemetery
*	Monument		Mountain Pass
<u> </u>	Mountain Peak		Museum
T J	Night life	(P)	Open Parking Area
果	Park and Recreation Area		Petrol station
4	Pharmacy	*	Place of Worship

Icon	Description	Icon	Description
<u>*</u>	Police Station	\searrow	Post Office
Q 1	Railway Station	ÐÎ	Rent-a car Parking
	Rest Area	41	Restaurant Area
$\dot{\Psi}$	Scenic or Panoramic View	(+ x abc	School
<u> </u>	Shop		Shopping Centre
	Stadium	24	Swimming Pool
•	Tennis Court	₽	Theatre
i	Tourist Information Office		Travel Agency
39 ****	Vehicle Equipment Provider	*	Veterinarian
20	Water Sports	₩	Winery
土	Yacht Basin	•	Zoological park (zoo)

Branded Points of Interest

Branded Points of Interest are available on some maps. These include well-known restaurants, accommodation providers, tourist attractions, petrol stations, etc. The icon will usually display the company logo.

Point of Interest categories by Mio

Icon	Description
-A ⁻	Favorite destination
1	Multiple route trip
A	My home
	NavPix

Point of Interest categories by subscription

Icon	Description
6	Safety Cameras
	Safety Camera (mobile)
	Safety Camera (average)
6	Red Light Camera

Traffic and other TMC Events

Each TMC Event is sorted in to one of nine categories. When an Event is received, one of the following icons will display:

Event	Avoided Event	Message Type	Event Description
A	A	Danger	There is a dangerous situation on the route; for example, people are on the road.
	A	Traffic	Any event that will cause a delay on a route.
		Weather	Weather conditions are adversely affecting a route; for example, there is ice on the road.
⚠	A	Warnings	There is a situation of which you should be aware on the route, but it is not serious enough to be considered a dangerous situation; for example, a minor accident has taken place.
<u> 2</u>	1	Forecast	An event is expected to occur on a route.
	A	Restrictions	There is a restricted flow of traffic on a route; for example, a lane has been closed on a motorway.
\oslash		Clearance	A Traffic Event that has now been cleared.
î	A	Information	All other events.
	A	Roadworks	Roadworks are taking place on a route.

If a Traffic or Clearance event has a recommended detour, the following icons will display:

Event	Avoided Event	Message Type	Event Description
		Traffic Detour	A <i>Traffic</i> Event, for which a detour is recommended.
		Clearance Re-route	A Clearance Event, for which a re-route is recommended.

Note: Avoided Event icons will only display on the 2D Map and 3D Map, at the Event location.

Safety Camera POIs

Mio products are designed to be used as an aid to safer driving. You can receive messages to alert you to locations of safety cameras, which will enable you to monitor your speed through these areas. Mio does not warrant that all types and locations of safety camera data are available, as cameras may be removed, relocated or new cameras installed. Mio does not condone speeding or any other failure to comply with your local traffic laws. It is your responsibility to drive within the posted speed limit at all times and to drive in a careful manner. Mio accepts NO liability whatsoever for you receiving any speeding fines or points on your license through using this device. Mio does not guarantee the accuracy of the data contained within this database either expressed or implied. In the event you receive a fine or any other penalty for speeding or contravention of any traffic law, or are involved in an accident, Mio is not responsible for any damages of any type. In some countries the data information regarding safety or speed cameras may conflict with local law and/or regulations. It is your responsibility to make sure that your use of the data is in compliance with local laws and/or regulations. Usage is at your own risk.

Disclaimer

Due to continued product development this information may change without notice. Mio does not warrant that this document is error-free. The screenshots and other presentations shown in this manual may differ from the actual screens and presentations generated by the actual product.

All such differences are minor and the actual product will deliver the described functionality as presented in this User Manual in all material respects.

Compliance



WARNING This product, its packaging and its components contain chemicals known to the State of California to cause cancer, birth defects or reproductive harm. This Notice is being provided in accordance with California's Proposition 65.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Marking labels located on the exterior of your Mio indicate the regulations that your model complies with. Please check the marking labels on your Mio and refer to the corresponding statements in this chapter. Some notices apply to specific models only.

Products with the CE marking comply with Radio & Telecommunication Terminal Equipment Directive (R&TTE) (1999/5/EC), the Electromagnetic Compatibility Directive (2004/108/EC) and the Low Voltage Directive (2006/95/EC) - issued by the Commission of the European Community. Compliance with these directives implies conformity to the following European Standards:

EN 301 489-1: Electronic compatibility and Radio spectrum Matters (ERM), Electromagnetic Compatibility (EMC) standard for radio equipment and services; Part 1: Common technical requirements.

EN 301 489-3: Electronic compatibility and Radio spectrum Matters (ERM), Electromagnetic Compatibility (EMC) standard for radio equipment and services; Part 3: Specific conditions for Short-Range Devices (SRD) operating on frequencies between 9 kHz and 40 GHz.

EN 301 489-17 (Bluetooth: For 300-Series only): Electronic compatibility and Radio spectrum Matters (ERM), Electromagnetic Compatibility (EMC) standard for radio equipment and services; Part 17: Specific conditions for 2,4 GHz wideband transmission systems and 5 GHz high performance RLAN equipment.

EN 300 328 (Bluetooth: For 300-Series only): Electromagnetic compatibility and Radio spectrum Matters (ERM); Wideband Transmission systems; Data transmission equipment operating in the 2,4 GPLz ISM band and using spread spectrum modulation techniques; Harmonized EN covering essential requirements under article 3.2 of the R&TTE Directive

EN 55022: Radio disturbance characteristics

EN 55024: Immunity characteristics

EN 6100-3-2: Limits for harmonic current emissions

EN 6100-3-3: Limitation of voltage fluctuation and flicker in low-voltage supply system

EN60950-1:2006/IEC 60950-1:2001: Product Safety

The manufacturer cannot be held responsible for modifications made by the User and the consequences thereof, which may alter the conformity of the product with the CE Marking.

The software is based in part on the work of the Independent JPEG Group.

The software application uses modified versions of the Minimal XML Library, Flickr Library and Python Library. The libraries and their use are covered by the GNU Lesser General Public License (www.gnu.org/licenses/lgpl.html). The modified source code is available from the following URLs:

- Minimal XML Library: http://download.mio.com/opensource/gnu/mxml.zip
- Flickr Library: http://download.mio.com/opensource/gnu/FlickrNet.zip
- Python Library: http://download.mio.com/opensource/gnu/python25.zip

Copyright

© 2008 MiTAC International Corporation. Mio is either a registered trademark or trademark of MiTAC International Corporation and is used under licence by Mio Technology Limited. All rights reserved.

The software contains proprietary information of MiTAC International Corporation; it is provided under a licence agreement containing restrictions on use and disclosure and is also protected by copyright law. Reverse engineering of the software is prohibited.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Mio.

Back-On-Track, Drive-Away, MioMore Desktop, Mio Connect, NavPix, MioMap and Turn-by-Turn are either registered trademarks or trademarks of MiTAC International Corporation and are used under licence by Mio Technology Limited. All rights reserved.

Microsoft, Windows, Windows Vista, and Internet Explorer are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. All rights reserved.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Mio Technology Limited is under license.

Location Identifiers © 2005 International Air Transport Association.

POI Data © 2007 InfoUSA.

All other trademarks and registrations are the property of their respective owners.

Published in New Zealand.

For more information

Online support

For 24/7 help and support with Mio products, visit our Technical Support website at: www.mio.com

You will find a fully searchable Frequently Asked Questions (FAQs) section for all Mio products.

At least 90% of our customers find answers to their questions at www.mio.com however if you require further support, you can use the online email option to contact us.

Mio Club

You can register your Mio with the Mio Club - a section of our website dedicated exclusively to owners of Mio navigation products: www.mio.com

As a registered Mio Club member, you'll have access to the safety camera database, software updates, a regular newsletter, tips, FAQs and much more!

